



**4**

<p>1- altoparlante 2- microfono 3- pulsante luci scale 4- pulsanti di chiamata</p>	<p>1- Lautsprecher 2- Mikrophon 3- Treppenlichtschalter 4- Ruftasten</p> <p>1- haut-parleur 2- micro 3- poussoir lumière escaliers 4- poussoirs d'appel</p> <p>1- loudspeaker 2- microphone 3- staircase lights pushbutton 4- call pushbuttons</p>	<p>1- altavoz 2- micrófono 3- pulsador luz escaleras 4- pulsadores de llamada</p> <p>1- luidspreker 2- microfoon 3- knop trappenhuisverlichting 4- knoppen oproep</p> <p>1- altifalante 2- microfone 3- botão da luz das escadas 4- botões de chamada</p>
--	--	---