

PRODUCT-DETAILS

6108/07

6108/07 Push-button coupler 4gang



Informations générales

Extension du type de produit	6108/07
Code de produit	2CKA006133A0222
EAN	4011395210932
Description courte	6108/07 Push-button coupler 4gang
Description longue	For contacting 2gang rocker 6230-2x-xxx, 6231-2x-xxx, 6232-2x-xxx, 6233-2x-xxx and 6234-2x-xxx. With integrated temperature sensor. Support of KNX functions through innovative colour concept (yellow=lighting, blue=blind, orange=RTC, magenta=scene and white=neutral/no function assigned) or standard illumination red/green. With middle position. The bus can be connected via enclosed terminal block.

Installation

Instructions et manuels	No document needed
-------------------------	--------------------

Technique

Fiche produit, informations techniques	2CKA001373B8904
Tension nominale (U _n)	24 V
Auxiliary Voltage AC/DC	24 V AC/DC
Number of Actuation Points	1

Compatible Bus Systems	KNX (TP)
Product Range	KNX
Type de montage	Flush Mounted
Type of Fastening	Mounting with Screw
Nombre de batteries	0
Application Function	Blind / Shutter / Shading Control Electrical Load and Light Control Room Climate Control

Environnement

Température de l'air ambiant	Operation -5 ... +45 °C
Indice de protection	IP20
Statut RoHS	Following EU Directive 2011/65/EU and Amendment 2015/863 July 22, 2019
Informations RoHS	2CKA200000E4583
REACH Declaration	2CKA309999E9999

Dimensions

Width in Number of Modular Spacings	1
Produit Largeur Net	71 mm
Produit Hauteur Net	71 mm
Produit Longueur Net	19 mm
Poids net	46.5 g
Profondeur d'encastrement (t ₂)	33 mm

Commande

Quantité minimum	1 pièce
Emballage Niveau 1 Unités	carton 1 pièce
Emballage Niveau 1 Poids	0.066 kg
Code douanier	85365080
Pays d'origine	Germany (DE)

Certificats et Déclarations (Numéro de document)

Déclaration de Conformité - CE	2CKA100000E1121
--------------------------------	-----------------

Classifications

ETIM 8	EC002466 - Touch sensor connector for bus system
ETIM 9	EC002466 - Touch sensor connector for bus system
Catégorie DEEE	5. Small Equipment (No External Dimension More Than 50 cm)
DEEE B2C / B2B	Business To Consumer
CN8	8536 50 80

Accessories

Identifier	Description	Type	Quantity	Unit Of Measure
2CKA001754A4373	1721 KA-20 Cover Frame 1gang(s) platinum - alpha exclusive	1721 KA-20	1	piece
2CKA001754A4382	1721 KA-21 Cover Frame 1gang(s) bronze - alpha exclusive	1721 KA-21	1	piece
2CKA001754A3831	1721 KA-22G Cover Frame 1gang(s) ivory - alpha exclusive	1721 KA-22G	1	piece
2CKA001754A2965	1721 KA-24G Cover Frame 1gang(s) studio white - alpha exclusive	1721 KA-24G	1	piece
2CKA001754A4520	1721 KA-260-500 Cover Frame 1gang(s) palladium - alpha exclusive	1721 KA-260-500	1	piece
2CKA001754A4509	1721 KA-266-500 Cover Frame 1gang(s) titanium - alpha exclusive	1721 KA-266-500	1	piece
2CKA001754A4516	1721 NS-212-500 Cover Frame 1gang(s) white - Busch-Duro 2000	1721 NS-212-500	1	piece
2CKA001754A4496	1721 NS-214-500 Cover Frame 1gang(s) alpine white - Reflex SI	1721 NS-214-500	1	piece
2CKA001754A4093	1721 NSKA-212 Cover Frame 1gang(s) white - Busch-Duro 2000 SI Linear	1721 NSKA-212	1	piece
2CKA001754A4497	1721 NSKA-214-500 Cover Frame 1gang(s) alpine white - Reflex SI Linear	1721 NSKA-214-500	1	piece
2CKA001754A4065	1721 NSKA-24G Cover Frame 1gang(s) studio white - alpha exclusive	1721 NSKA-24G	1	piece
2CKA001754A4713	1721-12-182K-101 Cover Frame 1gang(s) red - future linear	1721-12-182K-101	1	piece
2CKA001754A4240	1721-181K Cover Frame 1gang(s) anthracite - future linear	1721-181K	1	piece
2CKA001754A4168	1721-182 Cover Frame 1gang(s) ivory white - future	1721-182	1	piece
2CKA001754A4506	1721-182K-500 Cover Frame 1gang(s) ivory white - future linear	1721-182K-500	1	piece
2CKA001754A4529	1721-183K-500 Cover Frame 1gang(s) aluminium silver - future linear	1721-183K-500	1	piece
2CKA001754A4173	1721-184 Cover Frame 1gang(s) studio white - future	1721-184	1	piece
2CKA001754A4527	1721-184 NSK-500 Cover Frame 1gang(s) studio white - future linear	1721-184 NSK-500	1	piece
2CKA001754A4504	1721-184-500 Cover Frame 1gang(s) studio white - future	1721-184-500	1	piece
2CKA001754A4498	1721-184K-500 Cover Frame 1gang(s) studio white - future linear	1721-184K-500	1	piece
2CKA001754A4521	1721-20-500 Cover Frame 1gang(s) platinum - alpha nea	1721-20-500	1	piece
2CKA001754A4522	1721-21-500 Cover Frame 1gang(s) bronze - alpha nea	1721-21-500	1	piece
2CKA001754A4775	1721-223 Cover Frame 1gang(s) glass purple - Busch-axcent	1721-223	1	piece
2CKA001754A4760	1721-225 Cover Frame 1gang(s) glass sun - Busch-axcent	1721-225	1	piece
2CKA001754A4770	1721-226 Cover Frame 1gang(s) glass avocado - Busch-axcent	1721-226	1	piece
2CKA001754A4765	1721-227 Cover Frame 1gang(s) glass coral - Busch-axcent	1721-227	1	piece
2CKA001754A4755	1721-228 Cover Frame 1gang(s) glass ocean - Busch-axcent	1721-228	1	piece
2CKA001754A4780	1721-229 Cover Frame 1gang(s) glass oyster - Busch-axcent	1721-229	1	piece
2CKA001754A4512	1721-22G-500 Cover Frame 1gang(s) ivory - alpha nea	1721-22G-500	1	piece

2CKA001754A4790	1721-243 Cover Frame 1gang(s) paper brown - Busch-axcent	1721-243	1	piece
2CKA001754A4800	1721-245 Cover Frame 1gang(s) glass black - Busch-axcent	1721-245	1	piece
2CKA001754A4785	1721-248 Cover Frame 1gang(s) paper blue - Busch-axcent	1721-248	1	piece
2CKA001754A4503	1721-24G-500 Cover Frame 1gang(s) studio white - alpha nea	1721-24G-500	1	piece
2CKA001754A4400	1721-260 Cover Frame 1gang(s) palladium - alpha nea	1721-260	1	piece
2CKA001754A4391	1721-266 Cover Frame 1gang(s) titanium - alpha nea	1721-266	1	piece
2CKA001754A4688	1721-270-500 Cover Frame 1gang(s) platinum - Busch-axcent	1721-270-500	1	piece
2CKA001754A4708	1721-275-500 Cover Frame 1gang(s) black matt - Busch-axcent	1721-275-500	1	piece
2CKA001754A4698	1721-276-500 Cover Frame 1gang(s) titanium - Busch-axcent	1721-276-500	1	piece
2CKA001754A4437	1721-280 Cover Frame 1gang(s) white glass - Busch-axcent pur	1721-280	1	piece
2CKA001754A4409	1721-281 Cover Frame 1gang(s) black - Busch-axcent	1721-281	1	piece
2CKA001753A4126	1721-281/11 Cover Frame 1gang(s) black - Busch-axcent flat	1721-281/11	1	piece
2CKA001754A4543	1721-283 Cover Frame 1gang(s) brown glass - Busch-axcent	1721-283	1	piece
2CKA001754A4331	1721-284 Cover Frame 1gang(s) studio white - Busch-axcent	1721-284	1	piece
2CKA001753A4121	1721-284/11 Cover Frame 1gang(s) studio white - Busch-axcent flat	1721-284/11	1	piece
2CKA001754A4334	1721-285 Cover Frame 1gang(s) yellow - Busch-axcent	1721-285	1	piece
2CKA001754A4337	1721-286 Cover Frame 1gang(s) green - Busch-axcent	1721-286	1	piece
2CKA001754A4340	1721-287 Cover Frame 1gang(s) red - Busch-axcent	1721-287	1	piece
2CKA001754A4343	1721-288 Cover Frame 1gang(s) blue - Busch-axcent	1721-288	1	piece
2CKA001754A4805	1721-290 Cover Frame 1gang(s) slate grey - Busch-axcent	1721-290	1	piece
2CKA001754A4471	1721-291-500 Cover Frame 1gang(s) entrée-grey - Busch-axcent	1721-291-500	1	piece
2CKA001754A4491	1721-295-500 Cover Frame 1gang(s) château-black - Busch-axcent	1721-295-500	1	piece
2CKA001754A4795	1721-298 Cover Frame 1gang(s) concrete grey - Busch-axcent	1721-298	1	piece
2CKA001754A4481	1721-299-500 Cover Frame 1gang(s) maison-beige - Busch-axcent	1721-299-500	1	piece
2CKA001754A4505	1721-72-500 Cover Frame 1gang(s) ivory - impuls	1721-72-500	1	piece
2CKA001754A4514	1721-726-500 Cover Frame 1gang(s) chrome - impuls	1721-726-500	1	piece
2CKA001754A4507	1721-73-500 Cover Frame 1gang(s) solar gold - impuls	1721-73-500	1	piece
2CKA001754A4513	1721-74-500 Cover Frame 1gang(s) alpine white - impuls	1721-74-500	1	piece
2CKA001754A4222	1721-74-507 Cover Frame 1gang(s) alpine white - impuls	1721-74-507	1	piece
2CKA001754A4429	1721-774 Cover Frame 1gang(s) studio white matt - impuls	1721-774	1	piece
2CKA001754A4430	1721-774-507 Cover Frame 1gang(s) studio white matt - impuls	1721-774-507	1	piece

2CKA001754A4424	1721-775 Cover Frame 1gang(s) black matt - impuls	1721-775	1	piece
2CKA001754A4510	1721-79-500 Cover Frame 1gang(s) champagne metallic - impuls	1721-79-500	1	piece
2CKA001754A4225	1721-79-507 Cover Frame 1gang(s) champagne metallic - impuls	1721-79-507	1	piece
2CKA001754A4535	1721-80-500 Cover Frame 1gang(s) chrome - solo	1721-80-500	1	piece
2CKA001754A4538	1721-80G-500 Cover Frame 1gang(s) chrome gloss - solo	1721-80G-500	1	piece
2CKA001754A4442	1721-811 Cover Frame 1gang(s) white glass - carat	1721-811	1	piece
2CKA001754A4820	1721-815 Cover Frame 1gang(s) porcelain anthracite - carat	1721-815	1	piece
2CKA001754A4258	1721-821 Cover Frame 1gang(s) bronze - carat	1721-821	1	piece
2CKA001754A4356	1721-823-101 Cover Frame 1gang(s) gold - carat	1721-823-101	1	piece
2CKA001754A4322	1721-825 Cover Frame 1gang(s) glass black - carat	1721-825	1	piece
2CKA001754A4360	1721-826-101 Cover Frame 1gang(s) chrome - carat	1721-826-101	1	piece
2CKA001754A4605	1721-831-500 Cover Frame 1gang(s) anthracite - Busch-Dynasty	1721-831-500	1	piece
2CKA001754A4600	1721-832-500 Cover Frame 1gang(s) ivory white - Busch-Dynasty	1721-832-500	1	piece
2CKA001754A4575	1721-833-500 Cover Frame 1gang(s) polished brass decor anthracite - Busch-Dynasty	1721-833-500	1	piece
2CKA001754A4565	1721-835-500 Cover Frame 1gang(s) polished brass anthracite - Busch-Dynasty	1721-835-500	1	piece
2CKA001754A4570	1721-836-500 Cover Frame 1gang(s) polished brass decor ivory white - Busch-Dynasty	1721-836-500	1	piece
2CKA001754A4560	1721-838-500 Cover Frame 1gang(s) polished brass ivory white - Busch-Dynasty	1721-838-500	1	piece
2CKA001754A4595	1721-843-500 Cover Frame 1gang(s) antique brass decor anthracite - Busch-Dynasty	1721-843-500	1	piece
2CKA001754A4536	1721-84-500 Cover Frame 1gang(s) studio white - solo	1721-84-500	1	piece
2CKA001754A4585	1721-845-500 Cover Frame 1gang(s) antique brass anthracite - Busch-Dynasty	1721-845-500	1	piece
2CKA001754A4590	1721-846-500 Cover Frame 1gang(s) antique brass decor ivory white - Busch-Dynasty	1721-846-500	1	piece
2CKA001754A4580	1721-848-500 Cover Frame 1gang(s) antique brass ivory white - Busch-Dynasty	1721-848-500	1	piece
2CKA001754A4254	1721-860 Cover Frame 1gang(s) stainless steel - carat	1721-860	1	piece
2CKA001754A4500	1721-866K-500 Cover Frame 1gang(s) stainless steel - Pure Stainless Steel	1721-866K-500	1	piece
2CKA001754A4531	1721-884K-500 Cover Frame 1gang(s) studio white matt - future linear	1721-884K-500	1	piece
2CKA001754A4532	1721-885K-500 Cover Frame 1gang(s) black matt - future linear	1721-885K-500	1	piece
2CKA001754A4374	1722 KA-20 Cover Frame 2gang(s) platinum - alpha exclusive	1722 KA-20	1	piece
2CKA001754A4383	1722 KA-21 Cover Frame 2gang(s) bronze - alpha exclusive	1722 KA-21	1	piece
2CKA001754A3849	1722 KA-22G Cover Frame 2gang(s) ivory - alpha exclusive	1722 KA-22G	1	piece
2CKA001754A2999	1722 KA-24G Cover Frame 2gang(s) studio white - alpha exclusive	1722 KA-24G	1	piece
2CKA001754A4116	1722 KA-260 Cover Frame 2gang(s) palladium - alpha exclusive	1722 KA-260	1	piece
2CKA001754A4523	1722 KA-266-500 Cover Frame 2gang(s) titanium - alpha exclusive	1722 KA-266-500	1	piece

2CKA001754A2239	1722 NS-212 Cover Frame 2gang(s) white - Busch-Duro 2000	1722 NS-212	1	piece
2CKA001754A2163	1722 NS-214 Cover Frame 2gang(s) alpine white - Reflex SI	1722 NS-214	1	piece
2CKA001754A4094	1722 NSKA-212 Cover Frame 2gang(s) white - Busch-Duro 2000 SI Linear	1722 NSKA-212	1	piece
2CKA001754A4059	1722 NSKA-214 Cover Frame 2gang(s) alpine white - Reflex SI Linear	1722 NSKA-214	1	piece
2CKA001754A4066	1722 NSKA-24G Cover Frame 2gang(s) studio white - alpha exclusive	1722 NSKA-24G	1	piece
2CKA001754A4714	1722-12-182K-101 Cover Frame 2gang(s) red - future linear	1722-12-182K-101	1	piece
2CKA001754A4241	1722-181K Cover Frame 2gang(s) anthracite - future linear	1722-181K	1	piece
2CKA001754A4169	1722-182 Cover Frame 2gang(s) ivory white - future	1722-182	1	piece
2CKA001754A4231	1722-182K Cover Frame 2gang(s) ivory white - future linear	1722-182K	1	piece
2CKA001754A4530	1722-183K-500 Cover Frame 2gang(s) aluminium silver - future linear	1722-183K-500	1	piece
2CKA001754A4174	1722-184 Cover Frame 2gang(s) studio white - future	1722-184	1	piece
2CKA001754A4508	1722-184-500 Cover Frame 2gang(s) studio white - future	1722-184-500	1	piece
2CKA001754A4499	1722-184K-500 Cover Frame 2gang(s) studio white - future linear	1722-184K-500	1	piece
2CKA001754A4524	1722-20-500 Cover Frame 2gang(s) platinum - alpha nea	1722-20-500	1	piece
2CKA001754A1710	1722-21 Cover Frame 2gang(s) bronze - alpha nea	1722-21	1	piece
2CKA001754A4776	1722-223 Cover Frame 2gang(s) glass purple - Busch-axcent	1722-223	1	piece
2CKA001754A4761	1722-225 Cover Frame 2gang(s) glass sun - Busch-axcent	1722-225	1	piece
2CKA001754A4771	1722-226 Cover Frame 2gang(s) glass avocado - Busch-axcent	1722-226	1	piece
2CKA001754A4766	1722-227 Cover Frame 2gang(s) glass coral - Busch-axcent	1722-227	1	piece
2CKA001754A4756	1722-228 Cover Frame 2gang(s) glass ocean - Busch-axcent	1722-228	1	piece
2CKA001754A4781	1722-229 Cover Frame 2gang(s) glass oyster - Busch-axcent	1722-229	1	piece
2CKA001754A3799	1722-22G Cover Frame 2gang(s) ivory - alpha nea	1722-22G	1	piece
2CKA001754A4791	1722-243 Cover Frame 2gang(s) paper brown - Busch-axcent	1722-243	1	piece
2CKA001754A4801	1722-245 Cover Frame 2gang(s) glass black - Busch-axcent	1722-245	1	piece
2CKA001754A4786	1722-248 Cover Frame 2gang(s) paper blue - Busch-axcent	1722-248	1	piece
2CKA001754A4511	1722-24G-500 Cover Frame 2gang(s) studio white - alpha nea	1722-24G-500	1	piece
2CKA001754A4401	1722-260 Cover Frame 2gang(s) palladium - alpha nea	1722-260	1	piece
2CKA001754A4392	1722-266 Cover Frame 2gang(s) titanium - alpha nea	1722-266	1	piece
2CKA001754A4689	1722-270-500 Cover Frame 2gang(s) platinum - Busch-axcent	1722-270-500	1	piece
2CKA001754A4709	1722-275-500 Cover Frame 2gang(s) black matt - Busch-axcent	1722-275-500	1	piece
2CKA001754A4699	1722-276-500 Cover Frame 2gang(s) titanium - Busch-axcent	1722-276-500	1	piece

2CKA001754A4438	1722-280 Cover Frame 2gang(s) white glass - Busch-axcent pur	1722-280	1	piece
2CKA001754A4410	1722-281 Cover Frame 2gang(s) black - Busch-axcent	1722-281	1	piece
2CKA001753A4127	1722-281/11 Cover Frame 2gang(s) black - Busch-axcent flat	1722-281/11	1	piece
2CKA001754A4544	1722-283 Cover Frame 2gang(s) brown glass - Busch-axcent	1722-283	1	piece
2CKA001754A4332	1722-284 Cover Frame 2gang(s) studio white - Busch-axcent	1722-284	1	piece
2CKA001753A4122	1722-284/11 Cover Frame 2gang(s) studio white - Busch-axcent flat	1722-284/11	1	piece
2CKA001754A4335	1722-285 Cover Frame 2gang(s) yellow - Busch-axcent	1722-285	1	piece
2CKA001754A4338	1722-286 Cover Frame 2gang(s) green - Busch-axcent	1722-286	1	piece
2CKA001754A4341	1722-287 Cover Frame 2gang(s) red - Busch-axcent	1722-287	1	piece
2CKA001754A4344	1722-288 Cover Frame 2gang(s) blue - Busch-axcent	1722-288	1	piece
2CKA001754A4806	1722-290 Cover Frame 2gang(s) slate grey - Busch-axcent	1722-290	1	piece
2CKA001754A4472	1722-291-500 Cover Frame 2gang(s) entrée-grey - Busch-axcent	1722-291-500	1	piece
2CKA001754A4492	1722-295-500 Cover Frame 2gang(s) château-black - Busch-axcent	1722-295-500	1	piece
2CKA001754A4796	1722-298 Cover Frame 2gang(s) concrete grey - Busch-axcent	1722-298	1	piece
2CKA001754A4482	1722-299-500 Cover Frame 2gang(s) maison-beige - Busch-axcent	1722-299-500	1	piece
2CKA001754A4313	1722-72 Cover Frame 2gang(s) ivory - impuls	1722-72	1	piece
2CKA001754A4134	1722-726 Cover Frame 2gang(s) chrome - impuls	1722-726	1	piece
2CKA001754A3542	1722-73 Cover Frame 2gang(s) solar gold - impuls	1722-73	1	piece
2CKA001754A4525	1722-74-500 Cover Frame 2gang(s) alpine white - impuls	1722-74-500	1	piece
2CKA001754A4226	1722-74-507 Cover Frame 2gang(s) alpine white - impuls	1722-74-507	1	piece
2CKA001754A4431	1722-774 Cover Frame 2gang(s) studio white matt - impuls	1722-774	1	piece
2CKA001754A4432	1722-774-507 Cover Frame 2gang(s) studio white matt - impuls	1722-774-507	1	piece
2CKA001754A4425	1722-775 Cover Frame 2gang(s) black matt - impuls	1722-775	1	piece
2CKA001754A2528	1722-79 Cover Frame 2gang(s) champagne metallic - impuls	1722-79	1	piece
2CKA001754A4537	1722-80-500 Cover Frame 2gang(s) chrome - solo	1722-80-500	1	piece
2CKA001754A4327	1722-80G Cover Frame 2gang(s) chrome gloss - solo	1722-80G	1	piece
2CKA001754A4443	1722-811 Cover Frame 2gang(s) white glass - carat	1722-811	1	piece
2CKA001754A4821	1722-815 Cover Frame 2gang(s) porcelain anthracite - carat	1722-815	1	piece
2CKA001754A4259	1722-821 Cover Frame 2gang(s) bronze - carat	1722-821	1	piece
2CKA001754A4357	1722-823-101 Cover Frame 2gang(s) gold - carat	1722-823-101	1	piece
2CKA001754A4323	1722-825 Cover Frame 2gang(s) glass black - carat	1722-825	1	piece
2CKA001754A4361	1722-826-101 Cover Frame 2gang(s) chrome - carat	1722-826-101	1	piece
2CKA001754A4606	1722-831-500 Cover Frame 2gang(s) anthracite - Busch-Dynasty	1722-831-500	1	piece

2CKA001754A4601	1722-832-500 Cover Frame 2gang(s) ivory white - Busch-Dynasty	1722-832-500	1	piece
2CKA001754A4576	1722-833-500 Cover Frame 2gang(s) polished brass decor anthracite - Busch-Dynasty	1722-833-500	1	piece
2CKA001754A4566	1722-835-500 Cover Frame 2gang(s) polished brass anthracite - Busch-Dynasty	1722-835-500	1	piece
2CKA001754A4571	1722-836-500 Cover Frame 2gang(s) polished brass decor ivory white - Busch-Dynasty	1722-836-500	1	piece
2CKA001754A4561	1722-838-500 Cover Frame 2gang(s) polished brass ivory white - Busch-Dynasty	1722-838-500	1	piece
2CKA001754A4596	1722-843-500 Cover Frame 2gang(s) antique brass decor anthracite - Busch-Dynasty	1722-843-500	1	piece
2CKA001754A4539	1722-84-500 Cover Frame 2gang(s) studio white - solo	1722-84-500	1	piece
2CKA001754A4586	1722-845-500 Cover Frame 2gang(s) antique brass anthracite - Busch-Dynasty	1722-845-500	1	piece
2CKA001754A4591	1722-846-500 Cover Frame 2gang(s) antique brass decor ivory white - Busch-Dynasty	1722-846-500	1	piece
2CKA001754A4581	1722-848-500 Cover Frame 2gang(s) antique brass ivory white - Busch-Dynasty	1722-848-500	1	piece
2CKA001754A4255	1722-860 Cover Frame 2gang(s) stainless steel - carat	1722-860	1	piece
2CKA001754A4501	1722-866K-500 Cover Frame 2gang(s) stainless steel - Pure Stainless Steel	1722-866K-500	1	piece
2CKA001754A4415	1722-884K Cover Frame 2gang(s) studio white matt - future linear	1722-884K	1	piece
2CKA001754A4534	1722-885K-500 Cover Frame 2gang(s) black matt - future linear	1722-885K-500	1	piece
2CKA001754A4376	1723 KA-20 Cover Frame 3gang(s) platinum - alpha exclusive	1723 KA-20	1	piece
2CKA001754A4385	1723 KA-21 Cover Frame 3gang(s) bronze - alpha exclusive	1723 KA-21	1	piece
2CKA001754A3856	1723 KA-22G Cover Frame 3gang(s) ivory - alpha exclusive	1723 KA-22G	1	piece
2CKA001754A3021	1723 KA-24G Cover Frame 3gang(s) studio white - alpha exclusive	1723 KA-24G	1	piece
2CKA001754A4118	1723 KA-260 Cover Frame 3gang(s) palladium - alpha exclusive	1723 KA-260	1	piece
2CKA001754A4127	1723 KA-266 Cover Frame 3gang(s) titanium - alpha exclusive	1723 KA-266	1	piece
2CKA001754A3708	1723 NS-212 Cover Frame 3gang(s) white - Busch-Duro 2000	1723 NS-212	1	piece
2CKA001754A3724	1723 NS-214 Cover Frame 3gang(s) alpine white - Reflex SI	1723 NS-214	1	piece
2CKA001754A4096	1723 NSKA-212 Cover Frame 3gang(s) white - Busch-Duro 2000 SI Linear	1723 NSKA-212	1	piece
2CKA001754A4061	1723 NSKA-214 Cover Frame 3gang(s) alpine white - Reflex SI Linear	1723 NSKA-214	1	piece
2CKA001754A4068	1723 NSKA-24G Cover Frame 3gang(s) studio white - alpha exclusive	1723 NSKA-24G	1	piece
2CKA001754A4242	1723-181K Cover Frame 3gang(s) anthracite - future linear	1723-181K	1	piece
2CKA001754A4170	1723-182 Cover Frame 3gang(s) ivory white - future	1723-182	1	piece
2CKA001754A4232	1723-182K Cover Frame 3gang(s) ivory white - future linear	1723-182K	1	piece
2CKA001754A4533	1723-183K-500 Cover Frame 3gang(s) aluminium silver - future linear	1723-183K-500	1	piece
2CKA001754A4175	1723-184 Cover Frame 3gang(s) studio white - future	1723-184	1	piece
2CKA001754A4366	1723-184 NSK Cover Frame 3gang(s) studio white - future linear	1723-184 NSK	1	piece

2CKA001754A4502	1723-184K-500 Cover Frame 3gang(s) studio white - future linear	1723-184K-500	1	piece
2CKA001754A1637	1723-20 Cover Frame 3gang(s) platinum - alpha nea	1723-20	1	piece
2CKA001754A1728	1723-21 Cover Frame 3gang(s) bronze - alpha nea	1723-21	1	piece
2CKA001754A4777	1723-223 Cover Frame 3gang(s) glass purple - Busch-axcent	1723-223	1	piece
2CKA001754A4762	1723-225 Cover Frame 3gang(s) glass sun - Busch-axcent	1723-225	1	piece
2CKA001754A4772	1723-226 Cover Frame 3gang(s) glass avocado - Busch-axcent	1723-226	1	piece
2CKA001754A4767	1723-227 Cover Frame 3gang(s) glass coral - Busch-axcent	1723-227	1	piece
2CKA001754A4757	1723-228 Cover Frame 3gang(s) glass ocean - Busch-axcent	1723-228	1	piece
2CKA001754A3807	1723-22G Cover Frame 3gang(s) ivory - alpha nea	1723-22G	1	piece
2CKA001754A4792	1723-243 Cover Frame 3gang(s) paper brown - Busch-axcent	1723-243	1	piece
2CKA001754A4802	1723-245 Cover Frame 3gang(s) glass black - Busch-axcent	1723-245	1	piece
2CKA001754A4787	1723-248 Cover Frame 3gang(s) paper blue - Busch-axcent	1723-248	1	piece
2CKA001754A4518	1723-24G-500 Cover Frame 3gang(s) studio white - alpha nea	1723-24G-500	1	piece
2CKA001754A4403	1723-260 Cover Frame 3gang(s) palladium - alpha nea	1723-260	1	piece
2CKA001754A4394	1723-266 Cover Frame 3gang(s) titanium - alpha nea	1723-266	1	piece
2CKA001754A4690	1723-270-500 Cover Frame 3gang(s) platinum - Busch-axcent	1723-270-500	1	piece
2CKA001754A4710	1723-275-500 Cover Frame 3gang(s) black matt - Busch-axcent	1723-275-500	1	piece
2CKA001754A4700	1723-276-500 Cover Frame 3gang(s) titanium - Busch-axcent	1723-276-500	1	piece
2CKA001754A4439	1723-280 Cover Frame 3gang(s) white glass - Busch-axcent pur	1723-280	1	piece
2CKA001754A4411	1723-281 Cover Frame 3gang(s) black - Busch-axcent	1723-281	1	piece
2CKA001753A4128	1723-281/11 Cover Frame 3gang(s) black - Busch-axcent flat	1723-281/11	1	piece
2CKA001754A4545	1723-283 Cover Frame 3gang(s) brown glass - Busch-axcent	1723-283	1	piece
2CKA001754A4333	1723-284 Cover Frame 3gang(s) studio white - Busch-axcent	1723-284	1	piece
2CKA001753A4123	1723-284/11 Cover Frame 3gang(s) studio white - Busch-axcent flat	1723-284/11	1	piece
2CKA001754A4336	1723-285 Cover Frame 3gang(s) yellow - Busch-axcent	1723-285	1	piece
2CKA001754A4339	1723-286 Cover Frame 3gang(s) green - Busch-axcent	1723-286	1	piece
2CKA001754A4342	1723-287 Cover Frame 3gang(s) red - Busch-axcent	1723-287	1	piece
2CKA001754A4345	1723-288 Cover Frame 3gang(s) blue - Busch-axcent	1723-288	1	piece
2CKA001754A4807	1723-290 Cover Frame 3gang(s) slate grey - Busch-axcent	1723-290	1	piece
2CKA001754A4473	1723-291-500 Cover Frame 3gang(s) entrée-grey - Busch-axcent	1723-291-500	1	piece
2CKA001754A4493	1723-295-500 Cover Frame 3gang(s) château-black - Busch-axcent	1723-295-500	1	piece

2CKA001754A4797	1723-298 Cover Frame 3gang(s) concrete grey - Busch-axcent	1723-298	1	piece
2CKA001754A4483	1723-299-500 Cover Frame 3gang(s) maison-beige - Busch-axcent	1723-299-500	1	piece
2CKA001754A4314	1723-72 Cover Frame 3gang(s) ivory - impuls	1723-72	1	piece
2CKA001754A4135	1723-726 Cover Frame 3gang(s) chrome - impuls	1723-726	1	piece
2CKA001754A3591	1723-73 Cover Frame 3gang(s) solar gold - impuls	1723-73	1	piece
2CKA001754A2437	1723-74 Cover Frame 3gang(s) alpine white - impuls	1723-74	1	piece
2CKA001754A4433	1723-774 Cover Frame 3gang(s) studio white matt - impuls	1723-774	1	piece
2CKA001754A4426	1723-775 Cover Frame 3gang(s) black matt - impuls	1723-775	1	piece
2CKA001754A2536	1723-79 Cover Frame 3gang(s) champagne metallic - impuls	1723-79	1	piece
2CKA001754A4540	1723-80-500 Cover Frame 3gang(s) chrome - solo	1723-80-500	1	piece
2CKA001754A4328	1723-80G Cover Frame 3gang(s) chrome gloss - solo	1723-80G	1	piece
2CKA001754A4444	1723-811 Cover Frame 3gang(s) white glass - carat	1723-811	1	piece
2CKA001754A4260	1723-821 Cover Frame 3gang(s) bronze - carat	1723-821	1	piece
2CKA001754A4358	1723-823-101 Cover Frame 3gang(s) gold - carat	1723-823-101	1	piece
2CKA001754A4324	1723-825 Cover Frame 3gang(s) glass black - carat	1723-825	1	piece
2CKA001754A4362	1723-826-101 Cover Frame 3gang(s) chrome - carat	1723-826-101	1	piece
2CKA001754A4607	1723-831-500 Cover Frame 3gang(s) anthracite - Busch-Dynasty	1723-831-500	1	piece
2CKA001754A4602	1723-832-500 Cover Frame 3gang(s) ivory white - Busch-Dynasty	1723-832-500	1	piece
2CKA001754A4577	1723-833-500 Cover Frame 3gang(s) polished brass decor anthracite - Busch-Dynasty	1723-833-500	1	piece
2CKA001754A4567	1723-835-500 Cover Frame 3gang(s) polished brass anthracite - Busch-Dynasty	1723-835-500	1	piece
2CKA001754A4572	1723-836-500 Cover Frame 3gang(s) polished brass decor ivory white - Busch-Dynasty	1723-836-500	1	piece
2CKA001754A4562	1723-838-500 Cover Frame 3gang(s) polished brass ivory white - Busch-Dynasty	1723-838-500	1	piece
2CKA001754A4597	1723-843-500 Cover Frame 3gang(s) antique brass decor anthracite - Busch-Dynasty	1723-843-500	1	piece
2CKA001754A4541	1723-84-500 Cover Frame 3gang(s) studio white - solo	1723-84-500	1	piece
2CKA001754A4587	1723-845-500 Cover Frame 3gang(s) antique brass anthracite - Busch-Dynasty	1723-845-500	1	piece
2CKA001754A4592	1723-846-500 Cover Frame 3gang(s) antique brass decor ivory white - Busch-Dynasty	1723-846-500	1	piece
2CKA001754A4582	1723-848-500 Cover Frame 3gang(s) antique brass ivory white - Busch-Dynasty	1723-848-500	1	piece
2CKA001754A4256	1723-860 Cover Frame 3gang(s) stainless steel - carat	1723-860	1	piece
2CKA001754A4319	1723-866K Cover Frame 3gang(s) stainless steel - Pure Stainless Steel	1723-866K	1	piece
2CKA001754A4416	1723-884K Cover Frame 3gang(s) studio white matt - future linear	1723-884K	1	piece
2CKA001754A4421	1723-885K Cover Frame 3gang(s) black matt - future linear	1723-885K	1	piece
2CKA001754A4378	1724 KA-20 Cover Frame 4gang(s) platinum - alpha exclusive	1724 KA-20	1	piece
2CKA001754A4387	1724 KA-21 Cover Frame 4gang(s) bronze - alpha exclusive	1724 KA-21	1	piece

2CKA001754A4151	1724 KA-22G Cover Frame 4gang(s) ivory - alpha exclusive	1724 KA-22G	1	piece
2CKA001754A4155	1724 KA-24G Cover Frame 4gang(s) studio white - alpha exclusive	1724 KA-24G	1	piece
2CKA001754A4120	1724 KA-260 Cover Frame 4gang(s) palladium - alpha exclusive	1724 KA-260	1	piece
2CKA001754A4129	1724 KA-266 Cover Frame 4gang(s) titanium - alpha exclusive	1724 KA-266	1	piece
2CKA001754A4098	1724 NSKA-212 Cover Frame 4gang(s) white - Busch-Duro 2000 SI Linear	1724 NSKA-212	1	piece
2CKA001754A4063	1724 NSKA-214 Cover Frame 4gang(s) alpine white - Reflex SI Linear	1724 NSKA-214	1	piece
2CKA001754A4243	1724-181K Cover Frame 4gang(s) anthracite - future linear	1724-181K	1	piece
2CKA001754A4171	1724-182 Cover Frame 4gang(s) ivory white - future	1724-182	1	piece
2CKA001754A4233	1724-182K Cover Frame 4gang(s) ivory white - future linear	1724-182K	1	piece
2CKA001754A4309	1724-183K Cover Frame 4gang(s) aluminium silver - future linear	1724-183K	1	piece
2CKA001754A4176	1724-184 Cover Frame 4gang(s) studio white - future	1724-184	1	piece
2CKA001754A4367	1724-184 NSK Cover Frame 4gang(s) studio white - future linear	1724-184 NSK	1	piece
2CKA001754A4238	1724-184K Cover Frame 4gang(s) studio white - future linear	1724-184K	1	piece
2CKA001754A1645	1724-20 Cover Frame 4gang(s) platinum - alpha nea	1724-20	1	piece
2CKA001754A1736	1724-21 Cover Frame 4gang(s) bronze - alpha nea	1724-21	1	piece
2CKA001754A4778	1724-223 Cover Frame 4gang(s) glass purple - Busch-axcent	1724-223	1	piece
2CKA001754A4763	1724-225 Cover Frame 4gang(s) glass sun - Busch-axcent	1724-225	1	piece
2CKA001754A4768	1724-227 Cover Frame 4gang(s) glass coral - Busch-axcent	1724-227	1	piece
2CKA001754A3815	1724-22G Cover Frame 4gang(s) ivory - alpha nea	1724-22G	1	piece
2CKA001754A4793	1724-243 Cover Frame 4gang(s) paper brown - Busch-axcent	1724-243	1	piece
2CKA001754A4803	1724-245 Cover Frame 4gang(s) glass black - Busch-axcent	1724-245	1	piece
2CKA001754A4788	1724-248 Cover Frame 4gang(s) paper blue - Busch-axcent	1724-248	1	piece
2CKA001754A2908	1724-24G Cover Frame 4gang(s) studio white - alpha nea	1724-24G	1	piece
2CKA001754A4405	1724-260 Cover Frame 4gang(s) palladium - alpha nea	1724-260	1	piece
2CKA001754A4396	1724-266 Cover Frame 4gang(s) titanium - alpha nea	1724-266	1	piece
2CKA001754A4691	1724-270-500 Cover Frame 4gang(s) platinum - Busch-axcent	1724-270-500	1	piece
2CKA001754A4711	1724-275-500 Cover Frame 4gang(s) black matt - Busch-axcent	1724-275-500	1	piece
2CKA001754A4701	1724-276-500 Cover Frame 4gang(s) titanium - Busch-axcent	1724-276-500	1	piece
2CKA001754A4440	1724-280 Cover Frame 4gang(s) white glass - Busch-axcent pur	1724-280	1	piece
2CKA001754A4412	1724-281 Cover Frame 4gang(s) black - Busch-axcent	1724-281	1	piece
2CKA001753A4129	1724-281/11 Cover Frame 4gang(s) black - Busch-axcent flat	1724-281/11	1	piece

2CKA001754A4546	1724-283 Cover Frame 4gang(s) brown glass - Busch-axcent	1724-283	1	piece
2CKA001754A4346	1724-284 Cover Frame 4gang(s) studio white - Busch-axcent	1724-284	1	piece
2CKA001753A4124	1724-284/11 Cover Frame 4gang(s) studio white - Busch-axcent flat	1724-284/11	1	piece
2CKA001754A4348	1724-285 Cover Frame 4gang(s) yellow - Busch-axcent	1724-285	1	piece
2CKA001754A4350	1724-286 Cover Frame 4gang(s) green - Busch-axcent	1724-286	1	piece
2CKA001754A4352	1724-287 Cover Frame 4gang(s) red - Busch-axcent	1724-287	1	piece
2CKA001754A4354	1724-288 Cover Frame 4gang(s) blue - Busch-axcent	1724-288	1	piece
2CKA001754A4808	1724-290 Cover Frame 4gang(s) slate grey - Busch-axcent	1724-290	1	piece
2CKA001754A4474	1724-291-500 Cover Frame 4gang(s) entrée-grey - Busch-axcent	1724-291-500	1	piece
2CKA001754A4494	1724-295-500 Cover Frame 4gang(s) château-black - Busch-axcent	1724-295-500	1	piece
2CKA001754A4798	1724-298 Cover Frame 4gang(s) concrete grey - Busch-axcent	1724-298	1	piece
2CKA001754A4484	1724-299-500 Cover Frame 4gang(s) maison-beige - Busch-axcent	1724-299-500	1	piece
2CKA001754A4315	1724-72 Cover Frame 4gang(s) ivory - impuls	1724-72	1	piece
2CKA001754A4136	1724-726 Cover Frame 4gang(s) chrome - impuls	1724-726	1	piece
2CKA001754A3641	1724-73 Cover Frame 4gang(s) solar gold - impuls	1724-73	1	piece
2CKA001754A2445	1724-74 Cover Frame 4gang(s) alpine white - impuls	1724-74	1	piece
2CKA001754A4224	1724-74-507 Cover Frame 4gang(s) alpine white - impuls	1724-74-507	1	piece
2CKA001754A4434	1724-774 Cover Frame 4gang(s) studio white matt - impuls	1724-774	1	piece
2CKA001754A4435	1724-774-507 Cover Frame 4gang(s) studio white matt - impuls	1724-774-507	1	piece
2CKA001754A4427	1724-775 Cover Frame 4gang(s) black matt - impuls	1724-775	1	piece
2CKA001754A2544	1724-79 Cover Frame 4gang(s) champagne metallic - impuls	1724-79	1	piece
2CKA001754A4223	1724-79-507 Cover Frame 4gang(s) champagne metallic - impuls	1724-79-507	1	piece
2CKA001754A4107	1724-80 Cover Frame 4gang(s) chrome - solo	1724-80	1	piece
2CKA001754A4329	1724-80G Cover Frame 4gang(s) chrome gloss - solo	1724-80G	1	piece
2CKA001754A4445	1724-811 Cover Frame 4gang(s) white glass - carat	1724-811	1	piece
2CKA001754A4261	1724-821 Cover Frame 4gang(s) bronze - carat	1724-821	1	piece
2CKA001754A4359	1724-823-101 Cover Frame 4gang(s) gold - carat	1724-823-101	1	piece
2CKA001754A4325	1724-825 Cover Frame 4gang(s) glass black - carat	1724-825	1	piece
2CKA001754A4363	1724-826-101 Cover Frame 4gang(s) chrome - carat	1724-826-101	1	piece
2CKA001754A4608	1724-831-500 Cover Frame 4gang(s) anthracite - Busch-Dynasty	1724-831-500	1	piece
2CKA001754A4603	1724-832-500 Cover Frame 4gang(s) ivory white - Busch-Dynasty	1724-832-500	1	piece
2CKA001754A4578	1724-833-500 Cover Frame 4gang(s) polished brass decor anthracite - Busch-Dynasty	1724-833-500	1	piece
2CKA001754A4568	1724-835-500 Cover Frame 4gang(s) polished brass anthracite - Busch-Dynasty	1724-835-500	1	piece

2CKA001754A4573	1724-836-500 Cover Frame 4gang(s) polished brass decor ivory white - Busch-Dynasty	1724-836-500	1	piece
2CKA001754A4563	1724-838-500 Cover Frame 4gang(s) polished brass ivory white - Busch-Dynasty	1724-838-500	1	piece
2CKA001754A4112	1724-84 Cover Frame 4gang(s) studio white - solo	1724-84	1	piece
2CKA001754A4598	1724-843-500 Cover Frame 4gang(s) antique brass decor anthracite - Busch-Dynasty	1724-843-500	1	piece
2CKA001754A4588	1724-845-500 Cover Frame 4gang(s) antique brass anthracite - Busch-Dynasty	1724-845-500	1	piece
2CKA001754A4593	1724-846-500 Cover Frame 4gang(s) antique brass decor ivory white - Busch-Dynasty	1724-846-500	1	piece
2CKA001754A4583	1724-848-500 Cover Frame 4gang(s) antique brass ivory white - Busch-Dynasty	1724-848-500	1	piece
2CKA001754A4257	1724-860 Cover Frame 4gang(s) stainless steel - carat	1724-860	1	piece
2CKA001754A4320	1724-866K Cover Frame 4gang(s) stainless steel - Pure Stainless Steel	1724-866K	1	piece
2CKA001754A4417	1724-884K Cover Frame 4gang(s) studio white matt - future linear	1724-884K	1	piece
2CKA001754A4422	1724-885K Cover Frame 4gang(s) black matt - future linear	1724-885K	1	piece
2CKA001754A4380	1725 KA-20 Cover Frame 5gang(s) platinum - alpha exclusive	1725 KA-20	1	piece
2CKA001754A4389	1725 KA-21 Cover Frame 5gang(s) bronze - alpha exclusive	1725 KA-21	1	piece
2CKA001754A4153	1725 KA-22G Cover Frame 5gang(s) ivory - alpha exclusive	1725 KA-22G	1	piece
2CKA001754A4157	1725 KA-24G Cover Frame 5gang(s) studio white - alpha exclusive	1725 KA-24G	1	piece
2CKA001754A4122	1725 KA-260 Cover Frame 5gang(s) palladium - alpha exclusive	1725 KA-260	1	piece
2CKA001754A4131	1725 KA-266 Cover Frame 5gang(s) titanium - alpha exclusive	1725 KA-266	1	piece
2CKA001754A4244	1725-181K Cover Frame 5gang(s) anthracite - future linear	1725-181K	1	piece
2CKA001754A4172	1725-182 Cover Frame 5gang(s) ivory white - future	1725-182	1	piece
2CKA001754A4234	1725-182K Cover Frame 5gang(s) ivory white - future linear	1725-182K	1	piece
2CKA001754A4310	1725-183K Cover Frame 5gang(s) aluminium silver - future linear	1725-183K	1	piece
2CKA001754A4177	1725-184 Cover Frame 5gang(s) studio white - future	1725-184	1	piece
2CKA001754A4517	1725-184K-500 Cover Frame 5gang(s) studio white - future linear	1725-184K-500	1	piece
2CKA001754A1652	1725-20 Cover Frame 5gang(s) platinum - alpha nea	1725-20	1	piece
2CKA001754A1744	1725-21 Cover Frame 5gang(s) bronze - alpha nea	1725-21	1	piece
2CKA001754A3823	1725-22G Cover Frame 5gang(s) ivory - alpha nea	1725-22G	1	piece
2CKA001754A4794	1725-243 Cover Frame 5gang(s) paper brown - Busch-axcent	1725-243	1	piece
2CKA001754A4804	1725-245 Cover Frame 5gang(s) glass black - Busch-axcent	1725-245	1	piece
2CKA001754A2932	1725-24G Cover Frame 5gang(s) studio white - alpha nea	1725-24G	1	piece
2CKA001754A4407	1725-260 Cover Frame 5gang(s) palladium - alpha nea	1725-260	1	piece
2CKA001754A4398	1725-266 Cover Frame 5gang(s) titanium - alpha nea	1725-266	1	piece

2CKA001754A4692	1725-270-500 Cover Frame 5gang(s) platinum - Busch-axcent	1725-270-500	1	piece
2CKA001754A4712	1725-275-500 Cover Frame 5gang(s) black matt - Busch-axcent	1725-275-500	1	piece
2CKA001754A4702	1725-276-500 Cover Frame 5gang(s) titanium - Busch-axcent	1725-276-500	1	piece
2CKA001754A4441	1725-280 Cover Frame 5gang(s) white glass - Busch-axcent pur	1725-280	1	piece
2CKA001754A4413	1725-281 Cover Frame 5gang(s) black - Busch-axcent	1725-281	1	piece
2CKA001753A4130	1725-281/11 Cover Frame 5gang(s) black - Busch-axcent flat	1725-281/11	1	piece
2CKA001754A4547	1725-283 Cover Frame 5gang(s) brown glass - Busch-axcent	1725-283	1	piece
2CKA001754A4347	1725-284 Cover Frame 5gang(s) studio white - Busch-axcent	1725-284	1	piece
2CKA001753A4125	1725-284/11 Cover Frame 5gang(s) studio white - Busch-axcent flat	1725-284/11	1	piece
2CKA001754A4349	1725-285 Cover Frame 5gang(s) yellow - Busch-axcent	1725-285	1	piece
2CKA001754A4351	1725-286 Cover Frame 5gang(s) green - Busch-axcent	1725-286	1	piece
2CKA001754A4353	1725-287 Cover Frame 5gang(s) red - Busch-axcent	1725-287	1	piece
2CKA001754A4355	1725-288 Cover Frame 5gang(s) blue - Busch-axcent	1725-288	1	piece
2CKA001754A4809	1725-290 Cover Frame 5gang(s) slate grey - Busch-axcent	1725-290	1	piece
2CKA001754A4475	1725-291-500 Cover Frame 5gang(s) entrée-grey - Busch-axcent	1725-291-500	1	piece
2CKA001754A4495	1725-295-500 Cover Frame 5gang(s) château-black - Busch-axcent	1725-295-500	1	piece
2CKA001754A4799	1725-298 Cover Frame 5gang(s) concrete grey - Busch-axcent	1725-298	1	piece
2CKA001754A4485	1725-299-500 Cover Frame 5gang(s) maison-beige - Busch-axcent	1725-299-500	1	piece
2CKA001754A4316	1725-72 Cover Frame 5gang(s) ivory - impuls	1725-72	1	piece
2CKA001754A4137	1725-726 Cover Frame 5gang(s) chrome - impuls	1725-726	1	piece
2CKA001754A3690	1725-73 Cover Frame 5gang(s) solar gold - impuls	1725-73	1	piece
2CKA001754A2452	1725-74 Cover Frame 5gang(s) alpine white - impuls	1725-74	1	piece
2CKA001754A4436	1725-774 Cover Frame 5gang(s) studio white matt - impuls	1725-774	1	piece
2CKA001754A4428	1725-775 Cover Frame 5gang(s) black matt - impuls	1725-775	1	piece
2CKA001754A2551	1725-79 Cover Frame 5gang(s) champagne metallic - impuls	1725-79	1	piece
2CKA001754A4108	1725-80 Cover Frame 5gang(s) chrome - solo	1725-80	1	piece
2CKA001754A4330	1725-80G Cover Frame 5gang(s) chrome gloss - solo	1725-80G	1	piece
2CKA001754A4609	1725-831-500 Cover Frame 5gang(s) anthracite - Busch-Dynasty	1725-831-500	1	piece
2CKA001754A4604	1725-832-500 Cover Frame 5gang(s) ivory white - Busch-Dynasty	1725-832-500	1	piece
2CKA001754A4579	1725-833-500 Cover Frame 5gang(s) polished brass decor anthracite - Busch-Dynasty	1725-833-500	1	piece
2CKA001754A4569	1725-835-500 Cover Frame 5gang(s) polished brass anthracite - Busch-Dynasty	1725-835-500	1	piece
2CKA001754A4574	1725-836-500 Cover Frame 5gang(s) polished brass decor ivory white - Busch-Dynasty	1725-836-500	1	piece

2CKA001754A4564	1725-838-500 Cover Frame 5gang(s) polished brass ivory white - Busch-Dynasty	1725-838-500	1	piece
2CKA001754A4113	1725-84 Cover Frame 5gang(s) studio white - solo	1725-84	1	piece
2CKA001754A4599	1725-843-500 Cover Frame 5gang(s) antique brass decor anthracite - Busch-Dynasty	1725-843-500	1	piece
2CKA001754A4589	1725-845-500 Cover Frame 5gang(s) antique brass anthracite - Busch-Dynasty	1725-845-500	1	piece
2CKA001754A4594	1725-846-500 Cover Frame 5gang(s) antique brass decor ivory white - Busch-Dynasty	1725-846-500	1	piece
2CKA001754A4584	1725-848-500 Cover Frame 5gang(s) antique brass ivory white - Busch-Dynasty	1725-848-500	1	piece
2CKA001754A4321	1725-866K Cover Frame 5gang(s) stainless steel - Pure Stainless Steel	1725-866K	1	piece
2CKA001754A4418	1725-884K Cover Frame 5gang(s) studio white matt - future linear	1725-884K	1	piece
2CKA001754A4423	1725-885K Cover Frame 5gang(s) black matt - future linear	1725-885K	1	piece
2CKA001754A4375	1732 KA-20 Cover Frame 2gang(s) platinum - alpha exclusive	1732 KA-20	1	piece
2CKA001754A4384	1732 KA-21 Cover Frame 2gang(s) bronze - alpha exclusive	1732 KA-21	1	piece
2CKA001754A3864	1732 KA-22G Cover Frame 2gang(s) ivory - alpha exclusive	1732 KA-22G	1	piece
2CKA001754A3054	1732 KA-24G Cover Frame 2gang(s) studio white - alpha exclusive	1732 KA-24G	1	piece
2CKA001754A4117	1732 KA-260 Cover Frame 2gang(s) palladium - alpha exclusive	1732 KA-260	1	piece
2CKA001754A4126	1732 KA-266 Cover Frame 2gang(s) titanium - alpha exclusive	1732 KA-266	1	piece
2CKA001754A2213	1732 NS-212 Cover Frame 2gang(s) white - Busch-Duro 2000	1732 NS-212	1	piece
2CKA001754A2171	1732 NS-214 Cover Frame 2gang(s) alpine white - Reflex SI	1732 NS-214	1	piece
2CKA001754A4095	1732 NSKA-212 Cover Frame 2gang(s) white - Busch-Duro 2000 SI Linear	1732 NSKA-212	1	piece
2CKA001754A4060	1732 NSKA-214 Cover Frame 2gang(s) alpine white - Reflex SI Linear	1732 NSKA-214	1	piece
2CKA001754A4067	1732 NSKA-24G Cover Frame 2gang(s) studio white - alpha exclusive	1732 NSKA-24G	1	piece
2CKA001754A4368	1732-184 NSK Cover Frame 2gang(s) studio white - future linear	1732-184 NSK	1	piece
2CKA001754A1660	1732-20 Cover Frame 2gang(s) platinum - alpha nea	1732-20	1	piece
2CKA001754A1751	1732-21 Cover Frame 2gang(s) bronze - alpha nea	1732-21	1	piece
2CKA001754A3757	1732-22G Cover Frame 2gang(s) ivory - alpha nea	1732-22G	1	piece
2CKA001754A4528	1732-24G-500 Cover Frame 2gang(s) studio white - alpha nea	1732-24G-500	1	piece
2CKA001754A4402	1732-260 Cover Frame 2gang(s) palladium - alpha nea	1732-260	1	piece
2CKA001754A4393	1732-266 Cover Frame 2gang(s) titanium - alpha nea	1732-266	1	piece
2CKA001754A4377	1733 KA-20 Cover Frame 3gang(s) platinum - alpha exclusive	1733 KA-20	1	piece
2CKA001754A4386	1733 KA-21 Cover Frame 3gang(s) bronze - alpha exclusive	1733 KA-21	1	piece
2CKA001754A3872	1733 KA-22G Cover Frame 3gang(s) ivory - alpha exclusive	1733 KA-22G	1	piece
2CKA001754A3088	1733 KA-24G Cover Frame 3gang(s) studio white - alpha exclusive	1733 KA-24G	1	piece

2CKA001754A4119	1733 KA-260 Cover Frame 3gang(s) palladium - alpha exclusive	1733 KA-260	1	piece
2CKA001754A4128	1733 KA-266 Cover Frame 3gang(s) titanium - alpha exclusive	1733 KA-266	1	piece
2CKA001754A3716	1733 NS-212 Cover Frame 3gang(s) white - Busch-Duro 2000	1733 NS-212	1	piece
2CKA001754A3732	1733 NS-214 Cover Frame 3gang(s) alpine white - Reflex SI	1733 NS-214	1	piece
2CKA001754A4097	1733 NSKA-212 Cover Frame 3gang(s) white - Busch-Duro 2000 SI Linear	1733 NSKA-212	1	piece
2CKA001754A4062	1733 NSKA-214 Cover Frame 3gang(s) alpine white - Reflex SI Linear	1733 NSKA-214	1	piece
2CKA001754A4069	1733 NSKA-24G Cover Frame 3gang(s) studio white - alpha exclusive	1733 NSKA-24G	1	piece
2CKA001754A4369	1733-184 NSK Cover Frame 3gang(s) studio white - future linear	1733-184 NSK	1	piece
2CKA001754A1678	1733-20 Cover Frame 3gang(s) platinum - alpha nea	1733-20	1	piece
2CKA001754A1769	1733-21 Cover Frame 3gang(s) bronze - alpha nea	1733-21	1	piece
2CKA001754A3765	1733-22G Cover Frame 3gang(s) ivory - alpha nea	1733-22G	1	piece
2CKA001754A2734	1733-24G Cover Frame 3gang(s) studio white - alpha nea	1733-24G	1	piece
2CKA001754A4404	1733-260 Cover Frame 3gang(s) palladium - alpha nea	1733-260	1	piece
2CKA001754A4395	1733-266 Cover Frame 3gang(s) titanium - alpha nea	1733-266	1	piece
2CKA001754A4379	1734 KA-20 Cover Frame 4gang(s) platinum - alpha exclusive	1734 KA-20	1	piece
2CKA001754A4388	1734 KA-21 Cover Frame 4gang(s) bronze - alpha exclusive	1734 KA-21	1	piece
2CKA001754A4152	1734 KA-22G Cover Frame 4gang(s) ivory - alpha exclusive	1734 KA-22G	1	piece
2CKA001754A4156	1734 KA-24G Cover Frame 4gang(s) studio white - alpha exclusive	1734 KA-24G	1	piece
2CKA001754A4121	1734 KA-260 Cover Frame 4gang(s) palladium - alpha exclusive	1734 KA-260	1	piece
2CKA001754A4130	1734 KA-266 Cover Frame 4gang(s) titanium - alpha exclusive	1734 KA-266	1	piece
2CKA001754A4099	1734 NSKA-212 Cover Frame 4gang(s) white - Busch-Duro 2000 SI Linear	1734 NSKA-212	1	piece
2CKA001754A4064	1734 NSKA-214 Cover Frame 4gang(s) alpine white - Reflex SI Linear	1734 NSKA-214	1	piece
2CKA001754A4370	1734-184 NSK Cover Frame 4gang(s) studio white - future linear	1734-184 NSK	1	piece
2CKA001754A1686	1734-20 Cover Frame 4gang(s) platinum - alpha nea	1734-20	1	piece
2CKA001754A1777	1734-21 Cover Frame 4gang(s) bronze - alpha nea	1734-21	1	piece
2CKA001754A3773	1734-22G Cover Frame 4gang(s) ivory - alpha nea	1734-22G	1	piece
2CKA001754A2809	1734-24G Cover Frame 4gang(s) studio white - alpha nea	1734-24G	1	piece
2CKA001754A4406	1734-260 Cover Frame 4gang(s) palladium - alpha nea	1734-260	1	piece
2CKA001754A4397	1734-266 Cover Frame 4gang(s) titanium - alpha nea	1734-266	1	piece
2CKA001754A4381	1735 KA-20 Cover Frame 5gang(s) platinum - alpha exclusive	1735 KA-20	1	piece
2CKA001754A4390	1735 KA-21 Cover Frame 5gang(s) bronze - alpha exclusive	1735 KA-21	1	piece

2CKA001754A4154	1735 KA-22G Cover Frame 5gang(s) ivory - alpha exclusive	1735 KA-22G	1	piece
2CKA001754A4158	1735 KA-24G Cover Frame 5gang(s) studio white - alpha exclusive	1735 KA-24G	1	piece
2CKA001754A4123	1735 KA-260 Cover Frame 5gang(s) palladium - alpha exclusive	1735 KA-260	1	piece
2CKA001754A4132	1735 KA-266 Cover Frame 5gang(s) titanium - alpha exclusive	1735 KA-266	1	piece
2CKA001754A1694	1735-20 Cover Frame 5gang(s) platinum - alpha nea	1735-20	1	piece
2CKA001754A1785	1735-21 Cover Frame 5gang(s) bronze - alpha nea	1735-21	1	piece
2CKA001754A3781	1735-22G Cover Frame 5gang(s) ivory - alpha nea	1735-22G	1	piece
2CKA001754A2833	1735-24G Cover Frame 5gang(s) studio white - alpha nea	1735-24G	1	piece
2CKA001754A4408	1735-260 Cover Frame 5gang(s) palladium - alpha nea	1735-260	1	piece
2CKA001754A4399	1735-266 Cover Frame 5gang(s) titanium - alpha nea	1735-266	1	piece
2CKA001799A0162	1760 Label Holder clear-transparent - Reflex SI	1760	1	piece
2CKA001799A0154	1761 Label Holder Without imprint clear-transparent - Reflex SI	1761	1	piece
2CKA001730A0275	2101-31 Cover Frame 1gang(s) brown - Allwetter 44 (IP 44)	2101-31	1	piece
2CKA001730A0258	2101-32 Cover Frame 1gang(s) white - Allwetter 44 (IP 44)	2101-32	1	piece
2CKA001730A0282	2101-32-500 Cover Frame 1gang(s) white - Allwetter 44 (IP 44)	2101-32-500	1	piece
2CKA001730A0276	2101-33 Cover Frame 1gang(s) aluminium silver - Allwetter 44 (IP 44)	2101-33	1	piece
2CKA001730A0191	2101-34 Cover Frame 1gang(s) alpine white - Allwetter 44 (IP 44)	2101-34	1	piece
2CKA001730A0281	2101-34-500 Cover Frame 1gang(s) alpine white - Allwetter 44 (IP 44)	2101-34-500	1	piece
2CKA001730A0225	2101-35 Cover Frame 1gang(s) anthracite - Allwetter 44 (IP 44)	2101-35	1	piece
2CKA001730A0277	2102-31 Cover Frame 2gang(s) brown - Allwetter 44 (IP 44)	2102-31	1	piece
2CKA001730A0266	2102-32 Cover Frame 2gang(s) white - Allwetter 44 (IP 44)	2102-32	1	piece
2CKA001730A0284	2102-32-500 Cover Frame 2gang(s) white - Allwetter 44 (IP 44)	2102-32-500	1	piece
2CKA001730A0278	2102-33 Cover Frame 2gang(s) aluminium silver - Allwetter 44 (IP 44)	2102-33	1	piece
2CKA001730A0209	2102-34 Cover Frame 2gang(s) alpine white - Allwetter 44 (IP 44)	2102-34	1	piece
2CKA001730A0283	2102-34-500 Cover Frame 2gang(s) alpine white - Allwetter 44 (IP 44)	2102-34-500	1	piece
2CKA001730A0233	2102-35 Cover Frame 2gang(s) anthracite - Allwetter 44 (IP 44)	2102-35	1	piece
2CKA001730A0279	2103-31 Cover Frame 3gang(s) brown - Allwetter 44 (IP 44)	2103-31	1	piece
2CKA001730A0274	2103-32 Cover Frame 3gang(s) white - Allwetter 44 (IP 44)	2103-32	1	piece
2CKA001730A0280	2103-33 Cover Frame 3gang(s) aluminium silver - Allwetter 44 (IP 44)	2103-33	1	piece
2CKA001730A0217	2103-34 Cover Frame 3gang(s) alpine white - Allwetter 44 (IP 44)	2103-34	1	piece
2CKA001730A0241	2103-35 Cover Frame 3gang(s) anthracite - Allwetter 44 (IP 44)	2103-35	1	piece
2CKA001725A0662	2511 JH-212 Cover Frame 1gang(s) white - Busch-Duro 2000	2511 JH-212	1	piece

2CKA001725A1009	2511 JH-214 Cover Frame 1gang(s) alpine white - Reflex SI	2511 JH-214	1	piece
2CKA001725A1552	2511-212-500 Cover Frame 1gang(s) white - Busch-Duro 2000	2511-212-500	1	piece
2CKA001725A0613	2511-212-506 Cover Frame 1gang(s) white - Busch-Duro 2000	2511-212-506	1	piece
2CKA001725A1463	2511-212-507 Cover Frame 1gang(s) white - Busch-Duro 2000	2511-212-507	1	piece
2CKA001725A1549	2511-212K-102-500 Cover Frame 1gang(s) white - Busch-Duro 2000 SI Linear	2511-212K-102-500	1	piece
2CKA001725A1536	2511-214-500 Cover Frame 1gang(s) alpine white - Reflex SI	2511-214-500	1	piece
2CKA001725A1464	2511-214-507 Cover Frame 1gang(s) alpine white - Reflex SI	2511-214-507	1	piece
2CKA001725A1539	2511-214K-102-500 Cover Frame 1gang(s) alpine white - Reflex SI Linear	2511-214K-102-500	1	piece
2CKA001725A1033	2511-215 Cover Frame 1gang(s) black - Reflex SI	2511-215	1	piece
2CKA001725A1563	2511-217-101 Cover Frame 1gang(s) red - Reflex SI	2511-217-101	1	piece
2CKA001725A1531	2511-91-507 Cover Frame 1gang(s) entrée-grey - Basic55	2511-91-507	1	piece
2CKA001725A1484	2511-92-507 Cover Frame 1gang(s) white - Basic55	2511-92-507	1	piece
2CKA001725A1501	2511-93-507 Cover Frame 1gang(s) champagne - Basic55	2511-93-507	1	piece
2CKA001725A1479	2511-94-507 Cover Frame 1gang(s) alpine white - Basic55	2511-94-507	1	piece
2CKA001725A1506	2511-95-507 Cover Frame 1gang(s) château-black - Basic55	2511-95-507	1	piece
2CKA001725A1511	2511-96-507 Cover Frame 1gang(s) chalet-white - Basic55	2511-96-507	1	piece
2CKA001725A1516	2511-97-507 Cover Frame 1gang(s) foyer-red - Basic55	2511-97-507	1	piece
2CKA001725A1521	2511-98-507 Cover Frame 1gang(s) bistro-blue - Basic55	2511-98-507	1	piece
2CKA001725A1526	2511-99-507 Cover Frame 1gang(s) maison-beige - Basic55	2511-99-507	1	piece
2CKA001725A1553	2512-212-500 Cover Frame 2gang(s) white - Busch-Duro 2000	2512-212-500	1	piece
2CKA001725A1465	2512-212-507 Cover Frame 2gang(s) white - Busch-Duro 2000	2512-212-507	1	piece
2CKA001725A1550	2512-212K-102-500 Cover Frame 2gang(s) white - Busch-Duro 2000 SI Linear	2512-212K-102-500	1	piece
2CKA001725A1537	2512-214-500 Cover Frame 2gang(s) alpine white - Reflex SI	2512-214-500	1	piece
2CKA001725A1466	2512-214-507 Cover Frame 2gang(s) alpine white - Reflex SI	2512-214-507	1	piece
2CKA001725A1540	2512-214K-102-500 Cover Frame 2gang(s) alpine white - Reflex SI Linear	2512-214K-102-500	1	piece
2CKA001725A1066	2512-215 Cover Frame 2gang(s) black - Reflex SI	2512-215	1	piece
2CKA001725A1532	2512-91-507 Cover Frame 2gang(s) entrée-grey - Basic55	2512-91-507	1	piece
2CKA001725A1485	2512-92-507 Cover Frame 2gang(s) white - Basic55	2512-92-507	1	piece
2CKA001725A1502	2512-93-507 Cover Frame 2gang(s) champagne - Basic55	2512-93-507	1	piece
2CKA001725A1480	2512-94-507 Cover Frame 2gang(s) alpine white - Basic55	2512-94-507	1	piece
2CKA001725A1507	2512-95-507 Cover Frame 2gang(s) château-black - Basic55	2512-95-507	1	piece

2CKA001725A1512	2512-96-507 Cover Frame 2gang(s) chalet-white - Basic55	2512-96-507	1	piece
2CKA001725A1517	2512-97-507 Cover Frame 2gang(s) foyer-red - Basic55	2512-97-507	1	piece
2CKA001725A1522	2512-98-507 Cover Frame 2gang(s) bistro-blue - Basic55	2512-98-507	1	piece
2CKA001725A1527	2512-99-507 Cover Frame 2gang(s) maison-beige - Basic55	2512-99-507	1	piece
2CKA001725A1554	2513-212-500 Cover Frame 3gang(s) white - Busch-Duro 2000	2513-212-500	1	piece
2CKA001725A0639	2513-212-506 Cover Frame 3gang(s) white - Busch-Duro 2000	2513-212-506	1	piece
2CKA001725A1468	2513-212-507 Cover Frame 3gang(s) white - Busch-Duro 2000	2513-212-507	1	piece
2CKA001725A1551	2513-212K-102-500 Cover Frame 3gang(s) white - Busch-Duro 2000 SI Linear	2513-212K-102-500	1	piece
2CKA001725A1538	2513-214-500 Cover Frame 3gang(s) alpine white - Reflex SI	2513-214-500	1	piece
2CKA001725A1541	2513-214K-102-500 Cover Frame 3gang(s) alpine white - Reflex SI Linear	2513-214K-102-500	1	piece
2CKA001725A1090	2513-215 Cover Frame 3gang(s) black - Reflex SI	2513-215	1	piece
2CKA001725A1533	2513-91-507 Cover Frame 3gang(s) entrée-grey - Basic55	2513-91-507	1	piece
2CKA001725A1486	2513-92-507 Cover Frame 3gang(s) white - Basic55	2513-92-507	1	piece
2CKA001725A1503	2513-93-507 Cover Frame 3gang(s) champagne - Basic55	2513-93-507	1	piece
2CKA001725A1481	2513-94-507 Cover Frame 3gang(s) alpine white - Basic55	2513-94-507	1	piece
2CKA001725A1508	2513-95-507 Cover Frame 3gang(s) château-black - Basic55	2513-95-507	1	piece
2CKA001725A1513	2513-96-507 Cover Frame 3gang(s) chalet-white - Basic55	2513-96-507	1	piece
2CKA001725A1518	2513-97-507 Cover Frame 3gang(s) foyer-red - Basic55	2513-97-507	1	piece
2CKA001725A1523	2513-98-507 Cover Frame 3gang(s) bistro-blue - Basic55	2513-98-507	1	piece
2CKA001725A1528	2513-99-507 Cover Frame 3gang(s) maison-beige - Basic55	2513-99-507	1	piece
2CKA001725A0647	2514-212-500 Cover Frame 4gang(s) white - Busch-Duro 2000	2514-212-500	1	piece
2CKA001725A1492	2514-212K-102 Cover Frame 4gang(s) white - Busch-Duro 2000 SI Linear	2514-212K-102	1	piece
2CKA001725A1543	2514-214-500 Cover Frame 4gang(s) alpine white - Reflex SI	2514-214-500	1	piece
2CKA001725A1497	2514-214K-102 Cover Frame 4gang(s) alpine white - Reflex SI Linear	2514-214K-102	1	piece
2CKA001725A1534	2514-91-507 Cover Frame 4gang(s) entrée-grey - Basic55	2514-91-507	1	piece
2CKA001725A1487	2514-92-507 Cover Frame 4gang(s) white - Basic55	2514-92-507	1	piece
2CKA001725A1504	2514-93-507 Cover Frame 4gang(s) champagne - Basic55	2514-93-507	1	piece
2CKA001725A1482	2514-94-507 Cover Frame 4gang(s) alpine white - Basic55	2514-94-507	1	piece
2CKA001725A1509	2514-95-507 Cover Frame 4gang(s) château-black - Basic55	2514-95-507	1	piece
2CKA001725A1514	2514-96-507 Cover Frame 4gang(s) chalet-white - Basic55	2514-96-507	1	piece
2CKA001725A1519	2514-97-507 Cover Frame 4gang(s) foyer-red - Basic55	2514-97-507	1	piece

2CKA001725A1524	2514-98-507 Cover Frame 4gang(s) bistro-blue - Basic55	2514-98-507	1	piece
2CKA001725A1529	2514-99-507 Cover Frame 4gang(s) maison-beige - Basic55	2514-99-507	1	piece
2CKA001725A0654	2515-212-500 Cover Frame 5gang(s) white - Busch-Duro 2000	2515-212-500	1	piece
2CKA001725A1467	2515-212-507 Cover Frame 5gang(s) white - Busch-Duro 2000	2515-212-507	1	piece
2CKA001725A1493	2515-212K-102 Cover Frame 5gang(s) white - Busch-Duro 2000 SI Linear	2515-212K-102	1	piece
2CKA001725A0969	2515-214 Cover Frame 5gang(s) alpine white - Reflex SI	2515-214	1	piece
2CKA001725A1498	2515-214K-102 Cover Frame 5gang(s) alpine white - Reflex SI Linear	2515-214K-102	1	piece
2CKA001725A1535	2515-91-507 Cover Frame 5gang(s) entrée-grey - Basic55	2515-91-507	1	piece
2CKA001725A1488	2515-92-507 Cover Frame 5gang(s) white - Basic55	2515-92-507	1	piece
2CKA001725A1505	2515-93-507 Cover Frame 5gang(s) champagne - Basic55	2515-93-507	1	piece
2CKA001725A1483	2515-94-507 Cover Frame 5gang(s) alpine white - Basic55	2515-94-507	1	piece
2CKA001725A1510	2515-95-507 Cover Frame 5gang(s) château-black - Basic55	2515-95-507	1	piece
2CKA001725A1515	2515-96-507 Cover Frame 5gang(s) chalet-white - Basic55	2515-96-507	1	piece
2CKA001725A1520	2515-97-507 Cover Frame 5gang(s) foyer-red - Basic55	2515-97-507	1	piece
2CKA001725A1525	2515-98-507 Cover Frame 5gang(s) bistro-blue - Basic55	2515-98-507	1	piece
2CKA001725A1530	2515-99-507 Cover Frame 5gang(s) maison-beige - Basic55	2515-99-507	1	piece
2CKA001726A0222	2516-901-507 Decorative Styling Frame attica / pigeon blue - Basic55	2516-901-507	1	piece
2CKA001726A0223	2516-902-507 Decorative Styling Frame silver metallic - Basic55	2516-902-507	1	piece
2CKA001726A0224	2516-903-507 Decorative Styling Frame light green - Basic55	2516-903-507	1	piece
2CKA001726A0225	2516-904-507 Decorative Styling Frame orange - Basic55	2516-904-507	1	piece
2CKA001726A0226	2516-905-507 Decorative Styling Frame yellow - Basic55	2516-905-507	1	piece
2CKA001726A0227	2516-906-507 Decorative Styling Frame apricot - Basic55	2516-906-507	1	piece
2CKA001726A0228	2516-907-507 Decorative Styling Frame luminous - Basic55	2516-907-507	1	piece
2CKA001726A0220	2516-92-507 Decorative Styling Frame white - Basic55	2516-92-507	1	piece
2CKA001726A0230	2516-93-507 Decorative Styling Frame champagne - Basic55	2516-93-507	1	piece
2CKA001726A0218	2516-94-507 Decorative Styling Frame alpine white - Basic55	2516-94-507	1	piece
2CKA001726A0232	2516-95-507 Decorative Styling Frame château-black - Basic55	2516-95-507	1	piece
2CKA001726A0234	2516-96-507 Decorative Styling Frame chalet-white - Basic55	2516-96-507	1	piece
2CKA001719A0111	2518-212 Cover Frame with Hinged Lid 1 gang white - Busch-Duro 2000	2518-212	1	piece
2CKA001719A0061	2518-214 Cover Frame 1gang(s) alpine white - Reflex SI	2518-214	1	piece

Catégories

Produits basse tension → Home and Building Automation → KNX → User Operation → Bus Coupling Units / Push Button Coupling Units → Push Button Coupling Units

