

PRODUCT-DETAILS

2520 LI-212

2520 LI-212 Rocker Switch/push button Single rocker white - Busch-Duro 2000



Informations générales

Extension du type de produit	2520 LI-212
Code de produit	2CKA001731A0272
EAN	4011395107805
Description courte	2520 LI-212 Rocker Switch/push button Single rocker white - Busch-Duro 2000
Description longue	With >Light< icon. For flush-mounted switch 1g1w, 1g2w, intermediate, push switch.

Installation

Instructions et manuels	No document needed
-------------------------	--------------------

Technique

Fiche produit, informations techniques	No document needed
Application	Switch/push button
Design Range	Busch-Duro 2000 Busch-Duro 2000 SI Linear
Type de montage	Flush Mounted
Type of Fastening	Clamp
Finition de surface	Untreated Glossy
Matériau	Duroplast

Model Number	Single rocker
RAL Number	RAL 1013 - Blanc perlé
Couleur	white

Environnement

Indice de protection	IP20
Statut RoHS	Following EU Directive 2011/65/EU and Amendment 2015/863 July 22, 2019
Informations RoHS	2CKA200000E1574
REACH Declaration	2CKA309999E9999

Dimensions

Produit Largeur Net	54 mm
Produit Hauteur Net	54 mm
Produit Longueur Net	20 mm
Poids net	20 g

Commande

Quantité minimum	1 pièce
Emballage Niveau 1 Unités	carton 10 pièce
Emballage Niveau 1 Poids	0.26 kg
Code douanier	85389099
Pays d'origine	Germany (DE)

Certificats et Déclarations (Numéro de document)

Déclaration de Conformité - CE	2CKA200000E1574
--------------------------------	-----------------

Classifications

ETIM 8	EC000011 - Control element/cover plate for domestic switching devices
ETIM 9	EC000011 - Control element/cover plate for domestic switching devices
Catégorie DEEE	Product Not in WEEE Scope
CN8	8538 90 99
eClass	V11.0 : 27144002

Accessories

Identifiant	Description	Type	Quantity	Unit Of Measure
2CKA001012A2131	2000/1 US-507 Flush Mounted Inserts Off switch 1-pole	2000/1 US-507	1	piece
2CKA001022A0656	2000/2 UK Switch insert 2-pole switch	2000/2 UK	1	piece
2CKA001012A2193	2000/2 US-101-500 Flush Mounted Inserts 2-2000/2 US-101 pole switch	2000/2 US-101-500	1	piece
2CKA001012A2196	2000/2 US-500 Flush Mounted Inserts 2-pole switch	2000/2 US-500	1	piece
2CKA001011A0816	2000/3 US Switch insert 3-pole switch	2000/3 US	1	piece

2CKA001012A2198	2000/6 US-500 Flush Mounted Inserts Two-way switch	2000/6 US-500	1	piece
2CKA001012A2110	2000/6 US-507 Flush Mounted Inserts Two-way switch	2000/6 US-507	1	piece
2CKA001012A2194	2000/6 USGL-500 Flush Mounted Inserts Two-way switch	2000/6 USGL-500	1	piece
2CKA001022A0659	2000/6 USK-500 Flush Mounted Inserts Two-way switch	2000/6 USK-500	1	piece
2CKA001012A1598	2000/6 USR-503 Insert Two-way switch	2000/6 USR-503	1	piece
2CKA001012A0954	2000/6/2 US Switch insert Two-way switch	2000/6/2 US	1	piece
2CKA001012A2199	2000/7 US-500 Flush Mounted Inserts Intermediate switch	2000/7 US-500	1	piece
2CKA001012A2130	2000/7 US-507 Flush Mounted Inserts Intermediate switch	2000/7 US-507	1	piece
2CKA001413A0483	2020 US-201 Switch insert 1 gang(s) Single push button 0 NC 1 NO	2020 US-201	1	piece
2CKA001413A0491	2020 US-205 Switch insert 2 gang(s) Series push button 0 NC 2 NO	2020 US-205	1	piece
2CKA001413A1105	2020 US-205-500 Flush Mounted Inserts 2 gang(s) Series push button	2020 US-205-500	1	piece
2CKA001413A1104	2020 US-206-500 Flush Mounted Inserts Single push button	2020 US-206-500	1	piece
2CKA001413A0574	2020 US-500 Flush Mounted Inserts Single push button	2020 US-500	1	piece
2CKA001413A1078	2020 US-507 Flush Mounted Inserts Single push button	2020 US-507	1	piece
2CKA001413A1109	2020 USGL-103 Flush Mounted Inserts Single push button	2020 USGL-103	1	piece
2CKA001413A1106	2020 USGL-500 Flush Mounted Inserts Single push button	2020 USGL-500	1	piece
2CKA001413A1107	2031 UP-500 Flush Mounted Inserts Single push button	2031 UP-500	1	piece
2CKA001012A2238	2400/5 USK-500 Flush Mounted Inserts Series switch	2400/5 USK-500	1	piece
2CKA001012A2232	2400/6 US-500 Flush Mounted Inserts Two-way switch	2400/6 US-500	1	piece
2CKA001754A4516	1721 NS-212-500 Cover Frame 1gang(s) white - Busch-Duro 2000	1721 NS-212-500	1	piece
2CKA001754A4093	1721 NSKA-212 Cover Frame 1gang(s) white - Busch-Duro 2000 SI Linear	1721 NSKA-212	1	piece
2CKA001754A2239	1722 NS-212 Cover Frame 2gang(s) white - Busch-Duro 2000	1722 NS-212	1	piece
2CKA001754A4094	1722 NSKA-212 Cover Frame 2gang(s) white - Busch-Duro 2000 SI Linear	1722 NSKA-212	1	piece
2CKA001754A3708	1723 NS-212 Cover Frame 3gang(s) white - Busch-Duro 2000	1723 NS-212	1	piece
2CKA001754A4096	1723 NSKA-212 Cover Frame 3gang(s) white - Busch-Duro 2000 SI Linear	1723 NSKA-212	1	piece
2CKA001754A4098	1724 NSKA-212 Cover Frame 4gang(s) white - Busch-Duro 2000 SI Linear	1724 NSKA-212	1	piece
2CKA001754A2213	1732 NS-212 Cover Frame 2gang(s) white - Busch-Duro 2000	1732 NS-212	1	piece
2CKA001754A4095	1732 NSKA-212 Cover Frame 2gang(s) white - Busch-Duro 2000 SI Linear	1732 NSKA-212	1	piece
2CKA001754A3716	1733 NS-212 Cover Frame 3gang(s) white - Busch-Duro 2000	1733 NS-212	1	piece
2CKA001754A4097	1733 NSKA-212 Cover Frame 3gang(s) white - Busch-Duro 2000 SI Linear	1733 NSKA-212	1	piece
2CKA001754A4099	1734 NSKA-212 Cover Frame 4gang(s) white - Busch-Duro 2000 SI Linear	1734 NSKA-212	1	piece
2CKA001725A0662	2511 JH-212 Cover Frame 1gang(s) white - Busch-Duro 2000	2511 JH-212	1	piece

2CKA001725A1552	2511-212-500 Cover Frame 1gang(s) white - Busch-Duro 2000	2511-212-500	1	piece
2CKA001725A0613	2511-212-506 Cover Frame 1gang(s) white - Busch-Duro 2000	2511-212-506	1	piece
2CKA001725A1463	2511-212-507 Cover Frame 1gang(s) white - Busch-Duro 2000	2511-212-507	1	piece
2CKA001725A1549	2511-212K-102-500 Cover Frame 1gang(s) white - Busch-Duro 2000 SI Linear	2511-212K-102-500	1	piece
2CKA001725A1553	2512-212-500 Cover Frame 2gang(s) white - Busch-Duro 2000	2512-212-500	1	piece
2CKA001725A1465	2512-212-507 Cover Frame 2gang(s) white - Busch-Duro 2000	2512-212-507	1	piece
2CKA001725A1550	2512-212K-102-500 Cover Frame 2gang(s) white - Busch-Duro 2000 SI Linear	2512-212K-102-500	1	piece
2CKA001725A1554	2513-212-500 Cover Frame 3gang(s) white - Busch-Duro 2000	2513-212-500	1	piece
2CKA001725A0639	2513-212-506 Cover Frame 3gang(s) white - Busch-Duro 2000	2513-212-506	1	piece
2CKA001725A1468	2513-212-507 Cover Frame 3gang(s) white - Busch-Duro 2000	2513-212-507	1	piece
2CKA001725A1551	2513-212K-102-500 Cover Frame 3gang(s) white - Busch-Duro 2000 SI Linear	2513-212K-102-500	1	piece
2CKA001725A0647	2514-212-500 Cover Frame 4gang(s) white - Busch-Duro 2000	2514-212-500	1	piece
2CKA001725A1492	2514-212K-102 Cover Frame 4gang(s) white - Busch-Duro 2000 SI Linear	2514-212K-102	1	piece
2CKA001725A0654	2515-212-500 Cover Frame 5gang(s) white - Busch-Duro 2000	2515-212-500	1	piece
2CKA001725A1467	2515-212-507 Cover Frame 5gang(s) white - Busch-Duro 2000	2515-212-507	1	piece
2CKA001725A1493	2515-212K-102 Cover Frame 5gang(s) white - Busch-Duro 2000 SI Linear	2515-212K-102	1	piece
2CKA001719A0111	2518-212 Cover Frame with Hinged Lid 1 gang white - Busch-Duro 2000	2518-212	1	piece

Catégories

Produits basse tension → Wiring Accessories - Light Switch Ranges → Cover Plates (partly incl. Insert) → Mechanical Controls

