

PRODUCT-DETAILS

1789 KI-775

1789 KI-775 Cover Plate Switch/push button Single rocker black matt - impuls



General Information

Extended Product Type	1789 KI-775
Product ID	2CKA001753A0155
EAN	4011395127742
Catalog Description	1789 KI-775 Cover Plate Switch/push button Single rocker black matt - impuls
Long Description	With >Bell< icon. For flush-mounted push switch.

Installation

Instructions and Manuals	No document needed
--------------------------	--------------------

Technical

Data Sheet, Technical Information	No document needed
Application	Switch/push button
Design Range	impuls
Mounting Type	Flush Mounted
Type of Fastening	Clamp
Surface Finishing	Lacquered Matt
Material	Thermoplastic
Model Number	Single rocker
RAL Number	RAL 9005 - Jet Black
Color	black matt

Environmental

Degree of Protection	IP20
RoHS Status	Following EU Directive 2011/65/EU and Amendment 2015/863 July 22, 2019
RoHS Information	2CKA200000E2167
REACH Declaration	2CKA309999E9999

Dimensions

Product Net Width	71 mm
Product Net Height	71 mm
Product Net Depth / Length	20 mm
Product Net Weight	20 g

Ordering

Minimum Order Quantity	1 piece
Package Level 1 Units	carton 10 piece
Package Level 1 Gross Weight	0.27 kg
Customs Tariff Number	85389099
Country of Origin	Germany (DE)

Certificates and Declarations

Declaration of Conformity - CE	2CKA200000E2167
--------------------------------	-----------------

Classifications

ETIM 8	EC000011 - Control element/cover plate for domestic switching devices
ETIM 9	EC000011 - Control element/cover plate for domestic switching devices
WEEE Category	Product Not in WEEE Scope
CN8	8538 90 99
eClass	V11.0 : 27144002

Accessories

Identifier	Description	Type	Quantity	Unit Of Measure
2CKA001413A0897	2021/6 UK Switch insert Push button 1 rocker Single push button with Neon lamp 0 NO 0 NC	2021/6 UK	1	piece
2CKA001012A1705	2021/6 UNV Switch insert Push button 1 rocker Single push button 0 NO 0 NC	2021/6 UNV	1	piece
2CKA001012A2069	2021/6 UNV-201 Switch insert Push button 1 rocker Single push button 0 NO 0 NC	2021/6 UNV-201	1	piece
2CKA001413A1051	2021/6 US-201 Switch insert Push button 1 rocker Single push button 0 NO 0 NC	2021/6 US-201	1	piece
2CKA001022A0615	2001/6 UKGL-101 Switch insert Rocker/button 1 rocker Two-way switch with Neon lamp	2001/6 UKGL-101	1	piece
2CKA001022A0623	2001/2 UKGL-101 Switch insert Rocker/button 1 rocker 2-pole switch with Neon lamp	2001/2 UKGL-101	1	piece
2CKA001012A1622	2001/5 U Switch insert Rocker/button 2 rocker Series switch	2001/5 U	1	piece
2CKA001012A2111	2001/5 U-507 Flush Mounted Inserts Rocker/button 2 rocker Series switch	2001/5 U-507	1	piece
2CKA001012A2195	2001/6 U-500 Flush Mounted Inserts Rocker/button 1 rocker Two-way switch	2001/6 U-500	1	piece

2CKA001012A2109	2001/6 U-507 Flush Mounted Inserts Rocker/button 1 rocker Two-way switch	2001/6 U-507	1	piece
2CKA001012A1630	2001/7 U Switch insert Rocker/button 1 rocker Intermediate switch	2001/7 U	1	piece
2CKA001754A4505	1721-72-500 Cover Frame 1gang(s) ivory - impuls	1721-72-500	1	piece
2CKA001754A4514	1721-726-500 Cover Frame 1gang(s) chrome - impuls	1721-726-500	1	piece
2CKA001754A4507	1721-73-500 Cover Frame 1gang(s) solar gold - impuls	1721-73-500	1	piece
2CKA001754A4513	1721-74-500 Cover Frame 1gang(s) alpine white - impuls	1721-74-500	1	piece
2CKA001754A4222	1721-74-507 Cover Frame 1gang(s) alpine white - impuls	1721-74-507	1	piece
2CKA001754A4429	1721-774 Cover Frame 1gang(s) studio white matt - impuls	1721-774	1	piece
2CKA001754A4430	1721-774-507 Cover Frame 1gang(s) studio white matt - impuls	1721-774-507	1	piece
2CKA001754A4424	1721-775 Cover Frame 1gang(s) black matt - impuls	1721-775	1	piece
2CKA001754A4510	1721-79-500 Cover Frame 1gang(s) champagne metallic - impuls	1721-79-500	1	piece
2CKA001754A4225	1721-79-507 Cover Frame 1gang(s) champagne metallic - impuls	1721-79-507	1	piece
2CKA001754A4313	1722-72 Cover Frame 2gang(s) ivory - impuls	1722-72	1	piece
2CKA001754A4134	1722-726 Cover Frame 2gang(s) chrome - impuls	1722-726	1	piece
2CKA001754A3542	1722-73 Cover Frame 2gang(s) solar gold - impuls	1722-73	1	piece
2CKA001754A4525	1722-74-500 Cover Frame 2gang(s) alpine white - impuls	1722-74-500	1	piece
2CKA001754A4226	1722-74-507 Cover Frame 2gang(s) alpine white - impuls	1722-74-507	1	piece
2CKA001754A4431	1722-774 Cover Frame 2gang(s) studio white matt - impuls	1722-774	1	piece
2CKA001754A4432	1722-774-507 Cover Frame 2gang(s) studio white matt - impuls	1722-774-507	1	piece
2CKA001754A4425	1722-775 Cover Frame 2gang(s) black matt - impuls	1722-775	1	piece
2CKA001754A2528	1722-79 Cover Frame 2gang(s) champagne metallic - impuls	1722-79	1	piece
2CKA001754A4314	1723-72 Cover Frame 3gang(s) ivory - impuls	1723-72	1	piece
2CKA001754A4135	1723-726 Cover Frame 3gang(s) chrome - impuls	1723-726	1	piece
2CKA001754A3591	1723-73 Cover Frame 3gang(s) solar gold - impuls	1723-73	1	piece
2CKA001754A2437	1723-74 Cover Frame 3gang(s) alpine white - impuls	1723-74	1	piece
2CKA001754A4433	1723-774 Cover Frame 3gang(s) studio white matt - impuls	1723-774	1	piece
2CKA001754A4426	1723-775 Cover Frame 3gang(s) black matt - impuls	1723-775	1	piece
2CKA001754A2536	1723-79 Cover Frame 3gang(s) champagne metallic - impuls	1723-79	1	piece
2CKA001754A4315	1724-72 Cover Frame 4gang(s) ivory - impuls	1724-72	1	piece
2CKA001754A4136	1724-726 Cover Frame 4gang(s) chrome - impuls	1724-726	1	piece
2CKA001754A3641	1724-73 Cover Frame 4gang(s) solar gold - impuls	1724-73	1	piece
2CKA001754A2445	1724-74 Cover Frame 4gang(s) alpine white - impuls	1724-74	1	piece
2CKA001754A4224	1724-74-507 Cover Frame 4gang(s) alpine white - impuls	1724-74-507	1	piece
2CKA001754A4434	1724-774 Cover Frame 4gang(s) studio white matt - impuls	1724-774	1	piece
2CKA001754A4435	1724-774-507 Cover Frame 4gang(s) studio white matt - impuls	1724-774-507	1	piece
2CKA001754A4427	1724-775 Cover Frame 4gang(s) black matt - impuls	1724-775	1	piece
2CKA001754A2544	1724-79 Cover Frame 4gang(s) champagne metallic - impuls	1724-79	1	piece

2CKA001754A4223	1724-79-507 Cover Frame 4gang(s) champagne metallic - impuls	1724-79-507	1	piece
2CKA001754A4316	1725-72 Cover Frame 5gang(s) ivory - impuls	1725-72	1	piece
2CKA001754A4137	1725-726 Cover Frame 5gang(s) chrome - impuls	1725-726	1	piece
2CKA001754A3690	1725-73 Cover Frame 5gang(s) solar gold - impuls	1725-73	1	piece
2CKA001754A2452	1725-74 Cover Frame 5gang(s) alpine white - impuls	1725-74	1	piece
2CKA001754A4436	1725-774 Cover Frame 5gang(s) studio white matt - impuls	1725-774	1	piece
2CKA001754A4428	1725-775 Cover Frame 5gang(s) black matt - impuls	1725-775	1	piece
2CKA001754A2551	1725-79 Cover Frame 5gang(s) champagne metallic - impuls	1725-79	1	piece

Categories

Low Voltage Products and Systems → Wiring Accessories - Light Switch Ranges → Cover Plates (partly incl. Insert) → Mechanical Controls

