

PRODUCT-DETAILS

2511-212-506

2511-212-506 Cover Frame 1gang(s) white - Busch-Duro 2000



Informations générales

Extension du type de produit	2511-212-506
Code de produit	2CKA001725A0613
EAN	4011395096406
Description courte	2511-212-506 Cover Frame 1gang(s) white - Busch-Duro 2000
Description longue	For vertical or horizontal installation.

Installation

Instructions et manuels	No document needed
-------------------------	--------------------

Technique

Fiche produit, informations techniques	No document needed
Number of Gangs	1
Design Range	Busch-Duro 2000
Type de montage	Flush Mounted
Type of Fastening	Clamp
Sens de montage	Horizontal Vertical
Finition de surface	Untreated Glossy

Matériau	Duroplast
Label Space Provided	No
RAL Number	RAL 1013 - Blanc perlé
Couleur	white
Poids de la batterie	0 g

Environnement

Indice de protection	IP20
Statut RoHS	Following EU Directive 2011/65/EU and Amendment 2015/863 July 22, 2019
Informations RoHS	2CKA200000E1414
REACH Declaration	2CKA309999E9999

Dimensions

Produit Largeur Net	81 mm
Produit Hauteur Net	11 mm
Produit Longueur Net	81 mm
Poids net	25 g

Commande

Quantité minimum	1 pièce
Emballage Niveau 1 Unités	carton 10 pièce
Emballage Niveau 1 Poids	0.253 kg
Code douanier	85389099
Pays d'origine	Germany (DE)

Certificats et Déclarations (Numéro de document)

Déclaration de Conformité - CE	2CKA200000E1414
--------------------------------	-----------------

Classifications

ETIM 8	EC000007 - Cover frame for domestic switching devices
ETIM 9	EC000007 - Cover frame for domestic switching devices
Catégorie DEEE	Product Not in WEEE Scope
CN8	8538 90 99
eClass	V11.0 : 27144001

Accessories

Identifiant	Description	Type	Quantity	Unit Of Measure
2CKA001582A0360	1576 C-212 Cover Plate Busch-Infoline® white - Busch-Duro 2000	1576 C-212	1	piece
2CKA001710A3682	1794 TA-212 Cover plate with legend for Thermostat Turn button white - Busch-Duro 2000	1794 TA-212	1	piece
2CKA001710A3996	1795 HK-212 Cover plate with legend for Thermostat Turn button white - Busch-Duro 2000	1795 HK-212	1	piece

2CKA001710A4028	1795 HKEA-212 Cover plate with legend for Thermostat Turn button 1 sliding switch white - Busch-Duro 2000	1795 HKEA-212	1	piece
2CKA001710A3709	1795 TA-212 Cover plate with legend for Thermostat Turn button 1 sliding switch white - Busch-Duro 2000	1795 TA-212	1	piece
2CKA002013A5313	20 EUC/DVKS-212 Socket insert Protective Contact (SCHUKO) Safety Shutter white - Busch-Duro 2000	20 EUC/DVKS- 212	1	piece
2CKA002011A3788	20 EUC-212-507 Cover Plates (partly incl. Insert) Protective Contact (SCHUKO) white	20 EUC-212- 507	1	piece
2CKA002013A5466	20 EUCBL-13-212-101 Socket insert Protective Contact (SCHUKO) Safety Shutter withControl light; LED /Green green - Reflex SI	20 EUCBL-13- 212-101	1	piece
2CKA002013A5283	20 EUCBL-14-212 Socket insert Protective Contact (SCHUKO) Safety Shutter withControl light; LED /Green orange - Reflex SI	20 EUCBL-14- 212	1	piece
2CKA002013A5280	20 EUCBL-212 Socket insert Protective Contact (SCHUKO) Safety Shutter withControl light; LED /Green white - Busch-Duro 2000	20 EUCBL-212	1	piece
2CKA002013A5290	20 EUCBLI-212 Busch-steplight Socket insert Protective Contact (SCHUKO) Safety Shutter withNight light; LED /White white - Busch- Duro 2000	20 EUCBLI-212	1	piece
2CKA002013A5468	20 EUCKS-13-212-101 Socket insert Protective Contact (SCHUKO) Safety Shutter green - Reflex SI	20 EUCKS-13- 212-101	1	piece
2CKA002013A5310	20 EUCKS-14-212 Socket insert Protective Contact (SCHUKO) Safety Shutter orange - Reflex SI	20 EUCKS-14- 212	1	piece
2CKA002013A5317	20 EUCKS-14-212-10 Socket insert Protective Contact (SCHUKO) Safety Shutter orange - Reflex SI	20 EUCKS-14- 212-10	1	piece
2CKA002013A5471	20 EUKB-13-212-101 Socket insert Protective Contact (SCHUKO) Safety Shutter with Hinged Lid green - Reflex SI	20 EUKB-13- 212-101	1	piece
2CKA002013A5308	20 EUKB-14-212 Socket insert Protective Contact (SCHUKO) Safety Shutter with Hinged Lid orange - Reflex SI	20 EUKB-14- 212	1	piece
2CKA002013A5306	20 EUKB-212 Socket insert Protective Contact (SCHUKO) Safety Shutter with Hinged Lid white - Busch-Duro 2000	20 EUKB-212	1	piece
2CKA002013A5311	20 EUKNB-212 Socket insert Protective Contact (SCHUKO) Safety Shutter with Hinged Lid white - Busch-Duro 2000	20 EUKNB-212	1	piece
2CKA002013A5312	20 EURKS-212 Socket insert Protective Contact (SCHUKO) Safety Shutter white - Busch-Duro 2000	20 EURKS-212	1	piece
2CKA002013A5469	20EUCKS-13-212-102 Socket insert Protective Contact (SCHUKO) Safety Shutter green - Reflex SI	20EUCKS-13- 212-102	1	piece
2CKA002013A5315	2310 EUGL/VAB-212 Busch-Protector® Socket insert Protective Contact (SCHUKO) Safety Shutter white	2310 EUGL/VAB-212	1	piece
2CKA002011A3816	2310EUGL/VA-212-11 Busch-Protector® Socket insert Protective Contact (SCHUKO) white - Busch-Duro 2000	2310EUGL/VA- 212-11	1	piece
2CKA002099A0207	2399 UCKS-212 Cover Plates (partly incl. Insert) white	2399 UCKS- 212	1	piece
2CKA001731A1890	2505-212-507 Cover Plates (partly incl. Insert) Switch/push button Two-part rocker Without imprint white	2505-212-507	1	piece
2CKA001731A1889	2506-212-507 Cover Plates (partly incl. Insert) Switch/push button Single rocker Without imprint white	2506-212-507	1	piece

2CKA001724A4328	2531-212-500 Cover Plates (partly incl. Insert) SAT 2 gang white	2531-212-500	1	piece
2CKA001724A2865	2531-212-507 Cover Plates (partly incl. Insert) SAT 2 gang white	2531-212-507	1	piece
2CKA001731A1919	2562-212 Cover Busch-Infolicht® white - Busch-Duro 2000	2562-212	1	piece
2CKA006115A0474	6108/61-212-500 Coverplate f. CE	6108/61-212-500	1	piece
2CKA006155A0051	6109/03-212-500 Coverplate f. RTC	6109/03-212-500	1	piece
2CKA006132A0373	6122/10-212-500 BW standard	6122/10-212-500	1	piece
2CKA006430A0313	6430-212-102 Control Element for Venetian blind Single push button white - Busch-Duro 2000	6430-212-102	1	piece
2CKA006430A0285	6435-212 Cover plate with legend for Time switch white - Busch-Duro 2000	6435-212	1	piece
2CKA006470A0001	6476-212 Cover Plate for Proximity switch white	6476-212	1	piece
2CKA006400A0048	6477-212 Cover Plate PowerDock 1 gang white	6477-212	1	piece
2CKA006599A2888	6545-212 Control Element for Dimmer Two- part button white - Busch-Duro 2000	6545-212	1	piece
2CKA006730A0028	6731-212-500 WaveLine Cover Plates (partly incl. Insert) 1 channel whiteRadio Control	6731-212-500	1	piece
2CKA006730A0029	6732-212-500 WaveLine Cover Plates (partly incl. Insert) 2 channel whiteRadio Control	6732-212-500	1	piece
2CKA008200A0076	8253-212 Cover Plate Loudspeaker white - Busch-Duro 2000	8253-212	1	piece
2CKA006220A0245	CP-FCC-212 C-plate Fan Coil	CP-FCC-212	1	piece
2CKA006220A0210	CP-RTC-212 C-plate RT sensor unit	CP-RTC-212	1	piece
2CKA006220A0218	MD-F-1.0.1-212 Movement detector	MD-F-1.0.1-212	1	piece
2CKA006220A0220	MSA-F-1.1.1-212 Mov. detector/actuator 1g	MSA-F-1.1.1-212	1	piece
2CKA006200A0092	MSA-F-1.1.1-212-WL WL-Mov. detector/act. 1g	MSA-F-1.1.1-212-WL	1	piece
2CKA006220A0182	SR-1-212 Reflex SI / Busch-Duro 2000SI free@home white - Busch-Duro 2000	SR-1-212	1	piece
2CKA006220A0192	SR-2-212 Reflex SI / Busch-Duro 2000SI free@home white - Busch-Duro 2000	SR-2-212	1	piece
2CKA006220A0186	SRB-1-212 Reflex SI / Busch-Duro 2000SI free@home white - Busch-Duro 2000	SRB-1-212	1	piece
2CKA006220A0196	SRB-2-212 Reflex SI / Busch-Duro 2000SI free@home white - Busch-Duro 2000	SRB-2-212	1	piece
2CKA006220A0190	SRD-1-212 Reflex SI / Busch-Duro 2000SI free@home white - Busch-Duro 2000	SRD-1-212	1	piece
2CKA006220A0200	SRD-2-L-212 Reflex SI / Busch-Duro 2000SI free@home white - Busch-Duro 2000	SRD-2-L-212	1	piece
2CKA006220A0261	SRD-2-R-212 Reflex SI / Busch-Duro 2000SI free@home white - Busch-Duro 2000	SRD-2-R-212	1	piece
2CKA006220A0184	SRL-1-212 Reflex SI / Busch-Duro 2000SI free@home white - Busch-Duro 2000	SRL-1-212	1	piece
2CKA006220A0194	SRL-2-L-212 Reflex SI / Busch-Duro 2000SI free@home white - Busch-Duro 2000	SRL-2-L-212	1	piece
2CKA006220A0202	SRL-2-R-212 Reflex SI / Busch-Duro 2000SI free@home white - Busch-Duro 2000	SRL-2-R-212	1	piece
2CKA006220A0188	SRS-1-212 Reflex SI / Busch-Duro 2000SI free@home white - Busch-Duro 2000	SRS-1-212	1	piece
2CKA006220A0198	SRS-2-L-212 Reflex SI / Busch-Duro 2000SI free@home white - Busch-Duro 2000	SRS-2-L-212	1	piece
2CKA006220A0206	SRS-2-R-212 Reflex SI / Busch-Duro 2000SI free@home white - Busch-Duro 2000	SRS-2-R-212	1	piece

Catégories

Produits basse tension → Wiring Accessories - Light Switch Ranges → Frames

