# **OPTOTRONIC<sup>®</sup> OT 50/220-240/24**


Constant Voltage LED Power supply for 24V LED - Modules

### 1. Technical Data


Nominal Voltage	220 – 240 Vac
	220 – 240 Vdc
Input Voltage	198 – 264 Vac
	198 – 264 Vdc
Line Current, nominal	0,35A
Mains Frequency	0 / 50 / 60 Hz
Power Factor	0,95 @ 230 Vac
Interface	None
IP Rating	IP 20

Max Out Power	50 Watt
Output Voltage	24 Vdc (- 0,5V/+0,9V)
Efficiency	85% @ 230 Vac
Ambient Temperature Ta	-20°C to +45°C
Max. Case Temperature at Tc	+95°C
Max. Cable Length	10m
Max load per circuit breaker B10	12
Max load per circuit breaker B16	19


### 2. Connection Schemes



# 3. Safety



Power supplies can be connected in parallel on the primary side, but not on the secondary side



The installation of two or more OPTOTRONIC® OT 50/220-240/24 Power supplies with common "-" or "+" wiring is forbidden.



OSRAM AG www.osram.com

Steinerne Furt 62, 86167 Augsburg, Germany




# **OPTOTRONIC®** OT 50/220-240/24

Constant Voltage LED Power supply for 24V LED - Modules

## Wiring and Connection

- Ensure that the LED module load is within the range of rated voltage, current and power supply (see Technical data)
- Maximum output cable length is limited by EMI and cross diameter
- Use output cable sections adequate to the load demand
- The luminaire manufacturer is responsible for providing the required clearances and creepage distances and also for protection against electrical shock, especially for the line and load wires
- Wire preparation:




#### **Earth Connection**

OT 50/24 is a "Protection Class II" power supply, therefore ground connection is not required

# **Mounting and Environmental protection**

- The control gear is an independent type for luminaire integration
- Maximum permissible ambient temperature must not be exceeded. Make sure there is adequate space to avoid a build-up of heat. In critical installations the temperature at t<sub>c</sub> has to be controlled. Cfr drawing below:



Bottom view

### 2 General Note

- Power supplies must be installed by a qualified electrician
- Disconnected from mains supplies before wiring work
- For further information see also "OPTOTRONIC Technical guide" at www.osram.com



**OSRAM AG** 

www.osram.com

Steinerne Furt 62, 86167 Augsburg, Germany

