

Essentia Intelligent Mains Switching Input/Output Unit EME215-I

Instruction Sheet
R10125GB0



Schneider Electric Fire & Security Oy

Sokerilinnantie 11 C
FI-02600 Espoo, Finland
Tel: +358 10 446 511
Website: www.schneider-electric.com
Document number: R10125GB0
Published: 13.05.2019

© 2018 – Schneider Electric. All Rights Reserved. This information is only to be used as guidance. Subject to changes and errors.

Contents

1	Essentia Intelligent Mains Switching Input/Output Unit EME215-I	4
1.1	Status indications	4
1.2	Dimensions	4
1.3	Essentia intelligent mains switching input/output unit standard resistive monitoring mode connectivity diagram	5


1 Essentia Intelligent Mains Switching Input/Output Unit EME215-I

The Essentia intelligent mains switching input/output unit (FFS06720315) with isolator provides supervision of normally open contacts connected to a single pair of cables. It also provides a voltage free change over relay output capable of switching 250 V ac mains. There is a DIL switch to set the address. Address range is 1-126.

1.1 Status indications

Legend	LED Status	Description
RLY	Continuous Red	Relay Active
RLY	Continuous Yellow	Relay Fault
Poll/ISOL	Flashing Green	Polling LED
Poll/ISOL	Continuous Yellow	Isolator LED
I/P 1, IP 2	Continuous Yellow	Input Fault
I/P 1, IP 2	Continuous Red	Input Active

1.2 Dimensions



1.3 Essentia intelligent mains switching input/output unit standard resistive monitoring mode connectivity diagram

